

RJ45 field plug pro

AWG 26/1 - 22/1, AWG 27/7 - 22/7




130E405032-E 10G C6A
130G405032-E 25G
130H405032-E 40G

- de

Montagehinweis für den Installateur
- en

Mounting note for the installer
- fr

Instructions d'installation pour l'installateur
- 





i HINWEIS / NOTE / AVIS



Anschlussfehler vermeiden!
Vor dem Anschluss Montageanleitung sorgfältig lesen!

Avoid connection errors!
Read installation instructions carefully before connecting!

Éviter des erreurs de raccordement !
A lire attentivement avant de procéder au raccordement !









Anschlussbelegung / PIN assignments Affectation des fils aux contacts			
PIN Nr. / No. contact no.	T568A	T568B	Industrial Profinet
1	WH-GN	WH-OG	YE
2	GN	OG	OG
3	WH-OG	WH-GN	WH
4	BU	BU	-
5	WH-BU	WH-BU	-
6	OG	GN	BU
7	WH-BN	WH-BN	-
8	BN	BN	-



RJ45 field plug pro | AWG 26/1 - 22/1, AWG 27/7 - 22/7
130E405032-E | 130G405032-E | 130H405032-E

(de) Montagehinweis für den Installateur (en) Mounting note for the installer (fr) Instructions d'installation pour l'installateur



Demontage / Disassembly / Démontage

