

Software description Modbus RTU

Summary

Description of the standard software of the Modbus RTU modules:

General commands	3
MR-DO4 / MR-DOA4	6
MR-TO4	10
MR-DI4 / MR-DI4-IP	10
MR-DI10	15
MR-SI4	16
MR-DIO4/2 / MR-DIO4/2S / MR-DIO4/2-IP	22
MR-TP	37
MR-AO4	45
MR-AOP4	47
MR-AI8	49
MR-CI4	60
MR-AIO4/2-IP	61
MR-SM3	81
MR-Multi I/O 12DI/7AI/2AO/8DO	88
MR-LD6	104

General commands

Bit rate setting with Modbus commands

Parity and bit rate have the same value as with the setting by the address switches.
 If Parity or bit rate are 0, there will be no setting or storage.
 The register content is stored in the EEPROM.

Modbus Function "06 (0x06) Write Single Register"

Modbus Function "16 (0x10) Write Multiple Registers"

Request

Valid Register Address 0x41 (65)

Valid Register Value 2 Bytes

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0x53								Parity				Bit rate			

Bit 15-8: Magic-Number 0x53 = 83 as protection against accidental writing.
 The command will be further analyzed only with this number.

Bit 7-4	1	2	3
Parity	even	odd	none

Bit 3-0	1	2	3	4	5	6	7	8
Bit rate	1200	2400	4800	9600	19200	38400	57600	115200

Response

Echo of Request

Example for a frame:

Slave address	0x12	Rotary switch setting (18)
Function	0x06	Write Single Register
Register address Hi	0x00	
Register address Lo	0x41	Bit rate and Parity (65)
Register content Hi	0x53	Magic number
Register content Lo	0x15	Parity Even, 19200 Bit/s

All devices can be switched simultaneously with a Broadcast command (Slave address 0x00)
 However, it is advised not to do so as this may cause problems:

- Devices from other manufacturers may have under this address a register for a different purpose that will then be operated in the wrong way.

There is no feedback from the individual devices. Consequently the control cannot immediately recognize if the command was correctly received.

It is safer to address and switch each device individually. The device will then answer with the old settings of parity and bit rate. Switching will take place afterwards. However, the answer can get lost if the bus is disturbed.

When all devices are switched; it is advised to check communication. Any function of the device providing a feedback is suitable. If a single function is to be used being independent from the process periphery then the function „Diagnostic“ sub-function „Return Query Data“ is suitable, it returns the transferred data.

If bit rate and parity setting of a device are unknown it is possible to address the device successively with all combinations of bit rate and parity until the device answers. Try the most likely combinations first. Try the lower bit rates last as they take longer.

Test of the communication system

Modbus Function "08 (0x08) Diagnostics"

Subfunction "0 (0x0000) Return Query Data"

Data Field Any

Response: Echo of Request

Subfunction "1 (0x0001) Restart Communication Option"

Data Field 0x0000 or 0xFF00

Response: Echo of Request

Action: Clears all Error Counters, Restarts node

Subfunction "4 (0x0004) Force Listen Only Mode"

Data Field 0x0000

No Response

Action: No response until Node Reset or Function Code 08

Subcode 01

Subfunction "10 (0x000A) Clear Counters"

Data Field 0x0000

Response: Echo of Request

Action: Clears all Error Counters

Subfunction "11 (0x000B) Return Bus Message Count"

Data Field 0x0000

Response: Quantity of messages that the remote device has detected on the communications system since its last restart, clear counters operation, or power-up.

Subfunction "12 (0x000C) Return Bus Communication Error Count"

Data Field 0x0000

Response: Quantity of errors encountered by the remote device since its last restart, clear counters operation, or power-up. (CRC, Length <3, Parity, Framing

Subfunction "13 (0x000D) Return Bus Exception Error Count"

Data Field 0x0000

Response: Quantity of Modbus exception responses returned by the remote device since its last restart, clear counters operation, or power-up.

Subfunction "14 (0x000E) Return Slave Message Count"

Data Field 0x0000

Response: quantity of messages addressed to the remote device, or broadcast, that the remote device has processed since its last restart, clear counters operation, or power-up.

Subfunction "15 (0x000F) Return Slave No Response Count"

Data Field 0x0000

Response: Quantity of messages addressed to the remote device for which it has returned no response (neither a normal response nor an exception response), since its last restart, clear counters operation, or power-up.

MR-DO4 / MR-DOA4

I/O commands

Modbus Function "01 (0x01) Read Coils"

Request

Valid Coil Starting Address	0 .. 7
* for MR-DOA4 Address	4 .. 7 = 0
Valid Quantity of Outputs	1 .. 8

Response

Byte Count	1
Output Status	Bit0 .. Bit7

Bit	Information
0	0 = Status relay 1 off
	1 = Status relay 1 on
1	0 = Status relay 2 off
	1 = Status relay 2 on
2	0 = Status relay 3 off
	1 = Status relay 3 on
3	0 = Status relay 4 off
	1 = Status relay 4 on
4*	0 = relay 1 switched via bus
	1 = relay 1 switched via manual control
5*	0 = relay 2 switched via bus
	1 = relay 2 switched via manual control
6*	0 = relay 3 switched via bus
	1 = relay 3 switched via manual control
7*	0 = relay 4 switched via bus
	1 = relay 4 switched via manual control

Modbus Function "05 (0x05) Write Single Coil"

Request

Valid Output Address 0 .. 3
 Valid Output Value 0x0000 or 0xFF00

Response

Echo of the request

Modbus Function "15 (0x0F) Write Multiple Coils"

Request

Valid Coil Starting Address 0 .. 3
 Valid Quantity of Outputs 1 .. 4
 Valid Byte Count 1
 Output Value 0 or 1 in Bit0 .. Bit3

Bit	Information
0	0 = Status relay 1 off
	1 = Status relay 1 on
1	0 = Status relay 2 off
	1 = Status relay 2 on
2	0 = Status relay 3 off
	1 = Status relay 3 on
3	0 = Status relay 4 off
	1 = Status relay 4 on

Response

Function Code, Starting Address, Quantity of Outputs

Modbus Function "03 (0x03) Read Holding Registers"

Request

Valid Register Starting Address 0..1 or 66
 Valid Quantity of Registers 2 or 1

Response

Function Code, Byte Count, Register Values

Values Register 0:

Bit	Information
0	0 = Status relay 1 off
	1 = Status relay 1 on
1	0 = Status relay 2 off
	1 = Status relay 2 on
2	0 = Status relay 3 off
	1 = Status relay 3 on
3	0 = Status relay 4 off
	1 = Status relay 4 on
4	0 = relay 1 switched via bus
	1 = relay 1 switched via manual control
5	0 = relay 2 switched via bus
	1 = relay 2 switched via manual control
6	0 = relay 3 switched via bus
	1 = relay 3 switched via manual control
7	0 = relay 4 switched via bus
	1 = relay 4 switched via manual control

Values Register 1:

Bit	Information
0	0 = Initial state after Reset or communication; monitoring relay 1 off
	1 = Initial state after Reset or communication; monitoring relay 1 on
1	0 = Initial state after Reset or communication; monitoring relay 2 off
	1 = Initial state after Reset or communication; monitoring relay 2 on
2	0 = Initial state after Reset or communication; monitoring relay 3 off
	1 = Initial state after Reset or communication; monitoring relay 3 on
3	0 = Initial state after Reset or communication; monitoring relay 4 off
	1 = Initial state after Reset or communication; monitoring relay 4 on

Value Register 66:

Time constant for communication monitoring.

Register Value = 0 (0x0000) (default) there is no communication monitoring, all other values are for communication monitoring with a resolution of 10 ms.

0x0001 to 0xFFFF => 0.01 to 655.35 seconds = 10.9 minutes

Modbus Function "06 (0x06) Write Single Register"

Request

Register Address	0 or 1 or 66
Register Value	Bits 0 – 3 according to tables or the description above

Response

Echo of the request

Modbus Function "16 (0x10) Write Multiple Registers"

Request

Valid Register Starting Address	0 or 1 or 66
Valid Quantity of Registers	1 or 2
Byte Count	2 x Quantity of registers
Registers Value	Quantity of registers x 2 Byte Bits 0 – 3 according to tables

Response

Function Code, Register Starting Address, Quantity of Registers

Modbus Function "43 /14 (0x2B / 0x0E) Read Device Identification"

Request

Read Device ID code:	0x01
Object ID	0x00

Response

Device ID code	0x01
Conformity level	0x01
More follows	0x00
Next object ID	0x00
Number of objects	0x03
Object ID	0x00
Object Length	0x11
Object Value	"METZ CONNECT GmbH"
Object ID	0x01
Object Length	0x06
Object Value	"MR-DO4"
Object ID	0x02
Object Length	0x04
Object Value	"V1.4"

MR-TO4

I/O commands

Modbus Function "01 (0x01) Read Coils"

Request

Valid Coil Starting Address 0 .. 7
 Valid Quantity of Outputs 1 .. 8

Response

Byte Count 1
 Output Status Bit0 .. Bit7

Bit	Information
0	0 = Status Triac 1 off
	1 = Status Triac 1 on
1	0 = Status Triac 2 off
	1 = Status Triac 2 on
2	0 = Status Triac 3 off
	1 = Status Triac 3 on
3	0 = Status Triac 4 off
	1 = Status Triac 4 on
4*	0 = Triac 1 switched via bus
	1 = Triac 1 switched via manual control
5*	0 = Triac 2 switched via bus
	1 = Triac 2 switched via manual control
6*	0 = Triac 3 switched via bus
	1 = Triac 3 switched via manual control
7*	0 = Triac 4 switched via bus
	1 = Triac 4 switched via manual control

Modbus Function "05 (0x05) Write Single Coil"

Request

Valid Output Address 0 .. 3
 Valid Output Value 0x0000 or 0xFF00

Response

Echo of the request

Modbus Function "15 (0x0F) Write Multiple Coils"

Request

Valid Coil Starting Address 0 .. 3
 Valid Quantity of Outputs 1 .. 4
 Valid Byte Count 1
 Output Value 0 or 1 in Bit0 .. Bit3

Bit	Information
0	0 = Status Triac 1 off
	1 = Status Triac 1 on
1	0 = Status Triac 2 off
	1 = Status Triac 2 on
2	0 = Status Triac 3 off
	1 = Status Triac 3 on
3	0 = Status Triac 4 off
	1 = Status Triac 4 on

Response

Function Code, Starting Address, Quantity of Outputs

Modbus-Function "03 (0x03) Read Holding Registers"

Modbus-Function "06 (0x06) Write Single Register"

Modbus-Function "16 (0x10) Write Multiple Registers"

Holding Registers	
Adresse	Beschreibung
0	Bits 0-3 contain Coils 0-3, Bits 4-7 contain Coils 4-7 (Read only)
1	Bits 0-3 contain the basic setting for Coils 0-3, Factory setting 0, Storage in EEPROM
2 – 5	Operating modes of the Triac outputs 0: Direct control via Modbus 1: Impulse generator with variable period and duration Factory setting 0, Storage in EEPROM
6 – 9	Basic settings of the pulse durations Data type unsigned int16, Resolution, unit: per mil of the pulse period, Value range 0...1000, Factory setting 0, Storage in EEPROM
10 – 13	Pulse period Data type unsigned int16, Resolution, unit: 10 ms Value range 0...65535 for 0...655.35 s, Factory setting 0, Storage in EEPROM
14 – 17	Current pulse duration Data type unsigned int16, Resolution, unit: per mil of the pulse period, Value range 0...1000, is loaded from register 6-9 at power-on

Holding Registers	
Adresse	Beschreibung
66	<p>Time constant for connection monitoring</p> <p>At timeout the basic setting is stored in the registers 0 and 14-17. The time starts anew with each valid message addressed to the device.</p> <p>Data type unsigned int16, Resolution, unit: 10 ms, Factory setting 0 (monitoring off), Maximum 65535 (= 655.35 seconds = 10.9 minutes), Storage in EEPROM</p>

Modbus Function "43 /14 (0x2B / 0x0E) Read Device Identification"

Request

Read Device ID code: 0x01
Object ID 0x00

Response

Device ID code 0x01
Conformity level 0x01
More follows 0x00
Next object ID 0x00
Number of objects 0x03
Object ID 0x00
Object Length 0x11
Object Value "METZ CONNECT GmbH"
Object ID 0x01
Object Length 0x06
Object Value "MR-TO4"
Object ID 0x02
Object Length 0x04
Object Value "V1.5"

MR-DI4 / MR-DI4-IP



Modbus Function "02 (0x02) Read Discrete Inputs"

Request

Valid Input Starting Address 0 .. 3
 Valid Quantity of Inputs 1 .. 4

Response

Byte Count 1
 Input Status Bit0 .. Bit3 (Bit 4 .. 7 = 0)

Information

1 = Status input closed
 0 = Status input open

Modbus Function "04 (0x04) Read Input Registers"

Request

Valid Register Starting Address 0
 Valid Quantity of Registers 1

Response

Byte Count 2
 Values Register Input Status Bit 0..3

Modbus Function "43 /14 (0x2B / 0x0E) Read Device Identification"

Request

Read Device ID code: 0x01
 Object ID 0x00

Response

Device ID code 0x01
 Conformity level 0x01
 More follows 0x00
 Next object ID 0x00
 Number of objects 0x03
 Object ID 0x00
 Object Length 0x11
 Object Value "METZ CONNECT GmbH"
 Object ID 0x01
 Object Length 0x06
 Object Value "MR-DI4"
 Object ID 0x02
 Object Length 0x04
 Object Value "V1.4"

MR-DI10

Modbus Function "02 (0x02) Read Discrete Inputs"

Request

Valid Input Starting Address	0 .. 9
Valid Quantity of Inputs	1 .. 10

Response

Byte Count	1 or 2
Input Status	Bit0 .. Bit9

Information

- 1 = Status input closed
- 0 = Status input open

Modbus Function "04 (0x04) Read Input Registers"

Request

Valid Register Starting Address	0
Valid Quantity of Registers	1

Response

Byte Count	2
Values Register	Input Status Bit 0..9

Modbus Function "43 /14 (0x2B / 0x0E) Read Device Identification"

Request

Read Device ID code:	0x01
Object ID	0x00

Response

Device ID code	0x01
Conformity level	0x01
More follows	0x00
Next object ID	0x00
Number of objects	0x03
Object ID	0x00
Object Length	0x11
Object Value	"METZ CONNECT GmbH"
Object ID	0x01
Object Length	0x07
Object Value	"MR-DI10"
Object ID	0x02
Object Length	0x04
Object Value	"V1.4"

MR-SI4

I/O functions

Modbus Function "02 (0x02) Read Discrete Inputs"

Request

Valid Input Starting Address 0 .. 3
 Valid Quantity of Inputs 1 .. 4

Response

Byte Count 1
 Input Status Bit0 .. Bit3 (Bit 4 .. 7 = 0)

Information

1 = Status input closed
 0 = Status input open

Modbus Function "04 (0x04) Read Input Registers"

Request

Valid Register Starting Address 0
 Valid Quantity of Registers 21

Response

Byte Count 2
 Values Register Input Status Bit 0..3

Counter functions

The following functions are used to read or write the registers. The valid address ranges are indicated in brackets.

"04 (0x04) Read Input Registers" (0-20)
 „03 (0x03) Read Holding Registers" (0-51)
 "06 (0x06) Write Single Register" (20-51)
 "06 (0x06) Write Single Register" (65)
 "16 (0x10) Write Multiple Registers" (0-43, 65)

For long data types with a length of several registers, these registers are listed directly one after the other and the one with the highest value is indicated first. This data can only be transmitted as complete set.

Input Register (Read-Only)		
Address	Name	Description
0 – 11	IZ	Pulse counter Data type uint48_t (3 registers each)
12 – 19	BZ	Calculated counter reading Data type uint32_t (2 registers each)
20	INPUT	Bits 0-3 include Discrete Input 0-3

Holding Register		
Address	Name	Description
0 – 11	IT	Copy of the pulse counter after having pressed the key Data type uint48_t (3 registers each) (EEPROM)
12 – 19	AZ	Initial counter reading Data type uint32_t (2 registers each) Factory setting 0 (EEPROM)
20 – 23	IE	Pulses per unit Data type uint16_t (1 register each) Factory setting 1 (EEPROM)
24 – 27	WI	Transformation factor for current Data type uint16_t (1 register each) Factory setting 1 (EEPROM)
28 – 31	WU	Transformation factor for voltage Data type uint16_t (1 register each) Factory setting 1 (EEPROM)
32 – 35	WP	Operating mode for calculation with transformation factor Data type uint16_t (1 register each, only Bit 0 is valid) Value range 0...1, see below Factory setting 0 (EEPROM)
36 – 39	ZS	Format of the counter digit display Data type uint16_t (1 register each) (EEPROM) High-Byte for counter digits, Value range 0...9, factory setting 7, higher values are limited to 9. Low-Byte for places after the decimal point, Value range 0...3, factory setting 1, higher values are limited to 3.
40 – 43	TA	Flag for key activation Data type uint16_t (1 register each, only Flag in Bit 0) 0: key is blocked, 1: key is operational Factory setting 1 (EEPROM)
44 – 51	EZ	Simple counter, readable und writeable Data type uint32_t (2 registers each)
65	Bit rate	Codes for bit rate and Parity Factory setting 19200 bit/s, Even Parity (EEPROM)

Information on the application

Devices with an S0 interface are connected to the inputs of the MR-SI4, which output pulses at this interface. The MR-SI4 supplies the pulse interfaces with power; the pulse transmitters only contain potential-separated switching contacts or transistors.

The simple counters EZ only count the pulses at the respective input. Their value can be read or changed at any time via the Modbus. They have no connection to the other registers.

The following description deals with the application on electricity meters with an S0 interface. Meters for water or gas work in a similar way. However, other applications, such as simple pulse meters, are also possible.

A pulse counter IZ in the MR-SI4 counts the pulses at the input. A calculated counter reading BZ is constantly calculated from IZ and the configurable parameters IT, AZ, IE, WI, WU, WP, ZS.

To prevent unauthorised manipulation, the pulse counter IZ cannot be deleted or changed via the bus. This naturally restricts its direct application, but the calculated counter reading BZ can be used universally.

Operating mode for calculation with transformation factor

In the WP register, there is a code 0...1 that determines, together with the transformation factors WI and WU, the way how they are included in calculation. WP, WI and WU depend on whether the transformers are switched by the counters, whether the counter indicates the consumption in a primary or secondary way and whether the emitted pulses correspond primarily or secondarily to the consumption.

A difference must be made between the following electricity meter types:

Type 1: Directly measuring counter, display: primary, pulse: primary

Note: Indicates the real consumption
 Species: DIN rail counter with mechanical drum-type counting mechanism, Ferraris counter
 Formula type: $WP = 0$
 Factors: $WI = WU = 1$

$$BZ = \left(\frac{IZ - IT}{IE} + AZ \right) \cdot WI \cdot WU, \quad BZ = \text{counter reading} = \text{consumption}$$

Type 2: Transformer counter, display: primary, pulse: secondary

Note: Indicates the real consumption
 Species: counter with LCD display
 Formula type: $WP = 1$
 Factors: WI and WU correspond to the transformers

$$BZ = \left(\frac{IZ - IT}{IE} \cdot WI \cdot WU \right) + AZ, \quad BZ = \text{counter reading} = \text{consumption}$$

Type 3: Transformer counter, display: primary, pulse: primary

Note: Indicates the real consumption
 Species: counter with LCD display, multi-function counters
 Formula type: $WP = 0$
 Factors: $WI = WU = 1$

$$BZ = \left(\frac{IZ - IT}{IE} + AZ \right) \cdot WI \cdot WU, \quad BZ = \text{counter reading} = \text{consumption}$$

Type 4: Transformer counter, display: secondary, pulse: secondary

Note: Indicates the consumption reduced by the transformation factors
 Species: DIN rail counter with mechanical drum-type counting mechanism, Ferraris counter
 Formula type: $WP = 0$

Consumption and display of the transformer counter are different. Both can be calculated using a different configuration (WI, WU).

Factors: $WI = WU = 1$:
 The calculated counter reading corresponds to the display of the transformer counter.
 Species: DIN rail counter with mechanical drum-type counting mechanism, Ferraris counter.

$$BZ = \left(\frac{IZ - IT}{IE} + AZ \right) \cdot WI \cdot WU, \quad BZ = \text{counter reading or consumption}$$

Start of operation

The user reads on site the initial count from the electricity meter and presses the key on the MR-SI4. After this key press, the pulse counter of register IZ is copied into register IT. Afterwards, the user configures the MR-SI4 via the Modbus using a service program. The following must be entered:

- initial counter reading from the counter
- pulses per unit,
 e.g. indication on the electricity meter 2000 pulses per kWh

- formula type for calculation with transformation factors
- factor for current transformation,
e.g. indication on the transformer 200/5A → factor = 40
- factor for voltage conversion,
e.g. indication on the transformer 20000/100V → factor = 200
- number of digits and places after the decimal point
- deactivate the key to protect the IT register

Details for calculation

The calculated counter reading should behave exactly as the electricity meter. This requires that there should be no overflows and rounding errors for the intermediate results. Therefore, particularly large data types are used for counting and calculation

Every 60 milliseconds, a pulse can be emitted by the electricity meter. This results in up to 1,440,000 pulses per day or about 526,000,000 pulses per year.

If the pulse counter was realized with 4 bytes, it could be count to 4,294,967,295. At highest pulse frequency, this would be enough for approx. 8.2 years.

Therefore it is provided with 6 bytes and cannot overflow.

The number of places after the decimal point is considered as an additional multiplier with a power of ten during the calculation. Furthermore, it determines the place of the decimal point in the display of BZ and AZ.

As for the electricity counter which only has a specified number of decimal places, the number of places is limited with the last step in the calculation. This is why the calculated counter reading of the MR-SI4 overflows to 0 as often as the counter reading of the electricity meter.

Calculated counter reading if WP = 0:

$$BZ = ((\text{uint96_t}) (IZ - IT) * WU * WI * \text{power of ten [places after decimal point]} / IE + (\text{uint96_t}) AZ * WU * WI) \% \text{ power of ten [counter digits]}$$

Calculated counter reading if WP = 1:

$$BZ = ((\text{uint96_t}) (IZ - IT) * WU * WI * \text{power of ten [places after decimal point]} / IE + (\text{uint96_t}) AZ) \% \text{ power of ten [counter digits]}$$

Modbus Function "43 /14 (0x2B / 0x0E) Read Device Identification"

Request

Read Device ID code:	0x01
Object ID	0x00

Response

Device ID code	0x01
Conformity level	0x01
More follows	0x00
Next object ID	0x00
Number of objects	0x03
Object ID	0x00
Object Length	0x11
Object Value	"METZ CONNECT GmbH"
Object ID	0x01
Object Length	0x06
Object Value	"MR-SI4"
Object ID	0x02
Object Length	0x04
Object Value	"V2.2"

MR-DIO4/2 / MR-DIO4/2S / MR-DIO4/2-IP

Modbus Functions

The following functions serve to read and write the registers. Valid adress ranges are written in brackets, but depending on the operating mode not all registers have a function.

Read Discrete Inputs	(0 - 15)
Read Input Registers	(0, 1, 2)
Read Coils	(0 - 15)
Write Single Coil	(0 - 15)
Write Multiple Coils	(0 - 15)
Read Holding Registers	(0 - 19, 65, 66)
Write Single Register	(0 - 19, 65, 66)
Write Multiple Registers	(0 - 19, 65, 66)

Modbus Register

The purpose of the registers is briefly described here. A more detailed description follows below. In operating modes for fire dampers the registers are read and updated with a cycle of 100ms.

Discrete Inputs (Read-Only)		
Adr.	Name	Description
0	Input_1	Input switching state 1...4, Values: 0: Off, 1: On
1	Input_2	
2	Input_3	
3	Input_4	
8	Fault_1	Collecting error in channel 1/2 with operating mode Fire_Damper: The following single error bits are summarized here.
9	Fault_2	
10	FaultRun_1	Single error Runtime_Error in channel 1/2 in the Fire_Damper operating mode: Damper movement took too long.
11	FaultRun_2	
12	FaultMan_1	Single error manipulation in channel 1/2 in the Fire_Damper operating mode: Both limit switches are switched on simultaneously.
13	FaultMan_2	
14	FaultCom_1	Single error Update_Error in channel 1/2 with operating mode Fire_Damper: No communication came from the Modbus master for too long.
15	FaultCom_2	

Input Registers (Read-Only)		
Adr.	Name	Description
0	InputReg	Bits 0...15 include Discrete Inputs 0...3 and error bits.
1	InputRegToggelLH	Bits 0...15 include the cached Discrete Inputs 0...3 and error bits. With each detected change from low to high , the respective register bit is inverted (toggled) and the state is retained until the next change from low to high.
2	InputRegToggelHL	Bits 0...15 include the cached Discrete Inputs 0...3 and error bits. With each detected change from high to low , the respective register bit is inverted (toggled) and the state is retained until the next change from high to low.

Coils		
Adr.	Name	Description
0	Relay_1	Read: Actual switching state of relay 1...2
1	Relay_2	Write: Intended switching state of relay 1...2 Values: 0: off, 1: on
2	Hand_1	Read: Cause of the switching state of relay 1...2
3	Hand_2	Write: --- Values: 0: Modbus, 1: Toggle switch No manual operation for Motorized and LimitSwitch modes
4	RelaySet_1	Read: Intended switching state of relay 1...2
5	RelaySet_2	Write: Intended switching state of relay 1...2 Values: 0: off, 1: on
8	FaultReset_1	Read: 1: remains until the errors are reset, 0: after
9	FaultReset_2	Write: 0: no function, 1: reset all errors Only for Fire_Damper mode

Holding Registers		
Adr.	Name	Description
0	OutputReg	Read: Bits 0...15 = Coils 0...15 Write: Bits 0...1 = Intended switching state of relay 1...2 Bits 8...9 = Clear alarm if the bit is set
1	RelayDefault	Bits 0...1 contain the basic setting for relay 1...2, Factory setting 0, storage in EEPROM, at Direct_Control, Fire_Damper and Input_Logic_Control operating mode
2	OperMode_1	Operating mode for channel 1...2,

Holding Registers		
Adr.	Name	Description
3	OperMode_2	Values 0...9 see below, Factory setting 0, storage in EEPROM
4	DriveTime_1	Maximum duration of fire damper opening, Values: 0...6553.5 seconds, resolution 0.1 seconds, Factory setting 240 seconds, storage in EEPROM
5	DriveTime_2	
6	TurnOffTime_1	Maximum time for closing the fire damper, Values: 0...6553.5 seconds, resolution 0.1 seconds, Factory setting 35 seconds, storage in EEPROM
7	TurnOffTime_2	
8	RcvHeartBeat_1	Maximum duration between write accesses to ActuDrive_1...2, Values: 0...6553.5 seconds, resolution 0.1 seconds, Factory setting 0 seconds, storage in EEPROM
9	RcvHeartBeat_2	
10	ActuDrive_1	The position of the fire damper is controlled, values: open (1), close (2)
11	ActuDrive_2	
12	ActuPos_1	The position of the fire damper is reported, Values: open (1), close (2), running (3).
13	ActuPos_2	
14	ActuPos_1a	The position of the second fire damper is reported, values: inactive (0), open (1), close (2)
15	ActuPos_2a	
16	AlarmCode_1	Alarm codes are reported and reset, Values: OK (1), Runtime_Error (3), Manipulation (4), Update_Error (5), Alarm (6), Alarm_a (7)
17	AlarmCode_2	
18	RelayLogic_1	Allocation of the inputs 1..4 to relay 1 Bit 0..3: Relay 1 changes its state at 0 to 1 toggle from one of the marked inputs Bit 8..11: Relay 1 follows the state of the marked inputs. If more than one inputs is marked, an OR link of the inputs takes place. If a fire damper mode is set for relay 2, inputs 3 and 4 are no longer available for the logic and are no longer considered.
19	RelayLogic_2	Allocation of the inputs 1..4 to relay 2 Bit 0..3: Relay 2 changes its state at 0 to 1 toggle from one of the marked inputs Bit 8..11: Relay 2 follows the state of the marked inputs. If more than one inputs is marked, an OR link of the inputs takes place. If a fire damper mode is set for relay 1, inputs 1 and 2 are no longer available for the logic and are no longer considered.

Holding Registers		
Adr.	Name	Description
65	BaudCode	<p>Codes for baud rate and parity Factory setting 19200 Baud, even parity, storage in EEPROM</p> <p>Bit 0-3: Code for the baud rate. Code 0x01 0x02 0x03 0x04 0x05 0x06 0x07 0x08 Baud 1200 2400 4800 9600 19200 38400 57600 115200</p> <p>Bit 4-7: Code for parity. Code 0x10 0x20 0x30 Parity Even Odd None</p> <p>Bit 8-15: Value 0x53 enables modification with the commands Write single/multiple register. Then write this register as the only one.</p>
66	BusTimeout	<p>Time constant for connection monitoring with Direct_Control mode Values 0: inactive 1...65535: 0.01...655.35 seconds Factory setting 0, storage in EEPROM</p>

Overview of the operating modes

In register OperMode_1...2 the operating mode of the respective channel is set.
 Channel 1: Input 1...2 and relay 1, channel 2: Input 3...4 and relay 2.

Wert	Name	Description
0	Direct_Control	Direct control of inputs and outputs, Factory setting
1	Motorized_SafetyOpen	motorized fire damper, safe position open (smoke extraction flap)
2	Motorized_SafetyClose	motorized fire damper, safe position closed
3	LimitSwitch_Open_Close	mechanical fire protection flap with OPEN and CLOSE limit switch
4	LimitSwitch_Open	2 mechanical fire protection flaps only with OPEN limit switch (NO contact)
5	LimitSwitch_Close	2 mechanical fire protection flaps only with CLOSE limit switch (NC contact)
6	Fire_Damper	motorized fire damper
7	Motor_SafetyOpen_2	motorized fire damper, safe position open (smoke extraction flap)
8	Motor_SafetyClose_2	motorized fire damper, safe position closed
9	Input_Logic_Control	Relay is controlled depending on the input states

Operating mode Direct_Control

Address 0: The status of the digital inputs is reported.

(Input-Register InputReg)

Address 1: The toggle status if the digital inputs change from **low to high** is reported.

(Input-Register InputRegToggelLH)

Address 2: The toggle status if the digital inputs change from **high to low** is reported.

(Input-Register InputRegToggelHL)

The relay is controlled via the Modbus (Holding-Register OutputReg) and the toggle switches. The toggle switches have priority.

There is no link between the inputs and the relay.

After switching on or after the expiry of the connection monitoring (Holding Register BusTimeout), the default setting of the relay is valid (Holding Register RelayDefault).

The connection to the Modbus Master can be monitored with a watchdog timer. If the master or the connection fails, the outputs are switched to their basic state (safe state) and the red LED lights up. The timer restarts with every valid message addressed to the device. Only the device address is important, not the rest of the message content.

Operating mode Fire_Damper for fire dampers

The status of the digital inputs is reported (Input-Register InputReg). The limit switches (normally open contact) of the flaps are connected to the inputs.

The relay is controlled via the Modbus (Holding-Register OutputReg) and the toggle switches. The toggle switches have priority. The relay switches the motor of the damper. When it is on the damper is opened, when it is off the damper closes.

The inputs and the error messages do not influence the relay. The relay's basic setting (RelayDefault holding register) only applies after switching on.

The fire dampers are connected as follows:

Fire damper 1		Fire damper 2	
Input 1	Limit switch OPEN	Input 3	Limit switch OPEN
Input 2	Limit switch CLOSE	Input 4	Limit switch CLOSE
Relay 1	Motor	Relay 2	Motor

To support commissioning and maintenance, there is an error monitoring (Register InputReg and OutputReg). Only one of the single errors listed below is reported, after that the error detection is disabled. The collective error is reported at the same time as the individual error. The error is acknowledged by the Modbus Master by setting **FaultReset_1...2**.

The error **FaultRun_1...2** is reported when the adjustable maximum time for opening (DriveTime_1...2) or closing (TurnOffTime_1...2) the damper is exceeded. The time measurement starts when the relay is switched. Only outside the time measurement the position of the flaps is checked by means of the limit switches and the error is reported if the position is not as expected. The check can be switched off with the time constant 0. With manual operation the check is also switched off.

The error **FaultMan_1...2** is reported if both limit switches are switched on at the same time.

The error **FaultCom_1...2** is reported when the adjustable maximum time between Modbus commands is exceeded. This allows connection monitoring to be implemented. The timer restarts with every valid message addressed to the device. Only the device address is important, not the rest of the message content. The timer can be switched off with the time constant 0.

Operating mode Motorized and LimitSwitch for fire dampers

In these operating modes the relay is also controlled depending on the inputs and the error monitoring.

Registers for these operating modes

ActuDrive_1...2

Only for Motor... operating mode.

In this register the flap position is controlled.

Values: open (1), close (2), basic setting after reset is the normal position.

ActuPos_1...2

Operating modes Motor... and LimitSwitch_Open_Close:

In this register the flap position is reported.

The feedback comes from limit switches OPEN1, CLOSE1, OPEN2, CLOSE2 (normally open contact).

Values: open (1), close (2), running (3).

Operating modes LimitSwitch_Open and LimitSwitch_Close:

In this register the damper position is reported.

The feedback comes from limit switches at the inputs OPEN1/CLOSE1, OPEN2/CLOSE2 (normally open contact for LimitSwitch_Open, normally closed contact for LimitSwitch_Close).

Values: open (1), close (2).

ActuPos_1a...2a

Operating modes Motor... and LimitSwitch_Open_Close:

Values: inactive (0).

Operating modes LimitSwitch_Open and Limit_Switch_Close:

In this register the position of the second fire damper is reported.

The feedback comes from limit switches at the inputs OPEN1a/ZU1a, OPEN2a/ZU2a (normally open contact for LimitSwitch_Open, normally closed contact for LimitSwitch_Close).

Values: open (1), close (2).

AlarmCode_1...2

Error conditions are reported in this register. The first error code (3...7) remains stored until it is eliminated, only then another error message is possible.

The values and resetting of errors are described below.

Values for Motorized_SafetyOpen and Motorized_SafetyClose operating mode:
OK (1), Runtime_Error (3), Manipulation (4), Update_Error (5), Alarm (6).

Values for LimitSwitch_Open_Close mode:
OK (1), Manipulation (4), Alarm (6).

Values for operating modes LimitSwitch_Open and LimitSwitch_Close:
OK (1), alarm (6) for inputs OPEN1/CLOSED1, OPEN2/CLOSED2,
Alarm_a (7) for inputs OPEN1a/ZU1a, OPEN2a/ZU2a.
Alarm (6) has priority over Alarm_a (7) if both flaps are in fire position.

DriveTime_1...2

Only for Motorized_SafetyOpen and Motorized_SafetyClose operating mode.
In this register the maximum time for opening the flap is set.
In case of timeout the alarm code Runtime_Error is reported.
At value 0 the time measurement is switched off.
Values: 0...6553.5 seconds, resolution 0.1 seconds, factory setting 240 seconds.

TurnOffTime_1...2


Only for Motor... operating mode.
In this register, the maximum time for closing the flap is set.
In case of timeout the alarm code Runtime_Error is reported.
At value 0 the time measurement is switched off.
Values: 0...6553.5 seconds, resolution 0.1 seconds, factory setting 35 seconds.

RcvHeartBeat_1...2

Only for Motor... operating mode.
This register defines the maximum time between write accesses to ActuDrive_1...2
is set. With this a connection monitoring can be realized.
In case of timeout the alarm code Update_Error is reported.
If the value is 0, the time measurement is switched off.
Values: 0...6553.5 seconds, resolution 0.1 seconds, factory setting 0 seconds.

Overview of operating modes for fire dampers

Both channels are equal, their numbers are omitted in the image.



Limit switch of fire dampers

The limit switches are connected to the input terminals as follows

Terminal	Flap	Modes Motor..., LimitSwitch_Open_Close (each NO contact)	Flap	Modes LimitSwitch_Open (each NO contact), LimitSwitch_Close (each NC contact)
1 – C1	OPEN1	Flap 1 open	OPEN1/ CLOSED1	Flap 1
2 – C1	CLOSED1	Flap 1 closed	OPEN1a/ CLOSED1a	Flap 1a
3 – C1	OPEN2	Flap 2 open	OPEN2/ CLOSED2	Flap 2
4 – C1	CLOSED2	Flap 2 closed	OPEN2a/ CLOSED2a	Flap 2a

The operating modes LimitSwitch_Open and LimitSwitch_Close differ only in their names, the MR-DIO42 behaves identically in both.

- When the flap is completely open the contact is closed.
- When the flap is completely closed the contact is open.
- If the flap is partially open, the state of the corresponding end position applies.

Fire position

The fire position is derived from the limit switches depending on the operating mode.

Mode	Fire-Position if
Motorized_SafetyClose, Motor_SafetyClose_2	Flap not OPEN
Motorized_SafetyOpen, Motor_SafetyOpen_2	Flap not CLOSED
LimitSwitch_Open_Close	Flap not OPEN
LimitSwitch_Open	At least one Flap not OPEN
LimitSwitch_Close	At least one Flap CLOSED

If the position of the flap is the fire position and no other alarm code is reported yet, an alarm is reported in the alarm code register.

With the LimitSwitch_Open and LimitSwitch_Close operating modes, an alarm is reported for the first damper or Alarm_a for the second damper. Alarm has priority over Alarm_a.

In the operating modes Motor... there is a self-holding in the safe position via the fire position. The relay is then switched to the safe state. To move the fire damper to the normal position, the normal position is first written to ActuDrive and then AlarmCode is reset to OK. Then the alarm reset begins, in which the self-holding is interrupted.

In the case of fire dampers with a motor, there is this difference when deliberately controlling with the ActuDrive register to the safe position and back to the normal position:

Operating modes Motorised...: The fire position is reported as an alarm.

Operating modes Motor_..._2: The fire position is not reported as an alarm.

Error detection and alarm codes

There are 3 sources of error, which are reported as an alarm code and partly lead to an automatic control of the motorized fire damper.

Runtime_Error

(Operating mode Motor...)

The time during which the flap opens or closes can be measured. If the allowed time is exceeded, this error is reported.

The time measurement with DriveTime_1...2 starts when the relay is switched on (flap opens) and ends when the limit switches report the OPEN position.

Timing with TurnOffTime_1...2 starts when the relay is switched off (close damper) and ends when the limit switches report the CLOSED position.

The two time measurements can be switched off individually with the value 0. An error remains stored, the relay then switches to the safe position.

Possible causes: Flap jammed, limit switch defective, input for limit switch defective, cable to limit switch interrupted, cable to motor interrupted, motor defective.

Manipulation

(Operating mode Motor..., LimitSwitch_Open_Close)

If both limit switches are switched on at the same time, this error is reported.

In ActuPos_1...2 the value running is reported simultaneously.

An error remains stored, the relay is then switched off.

Possible causes: Limit switch defective, input for limit switch defective, cable to limit switch short-circuited.

Update_Error

(Operating mode Motor...)

The time interval of write accesses to ActuDrive_1...2 can be monitored. If the allowed duration (RcvHeartBeat_1...2) is exceeded, this error is reported.

The monitoring also starts if the error is reset or RcvHeartBeat is set unequal 0.

The time measurement can be switched off with the value 0.
An error remains stored, the relay then switches to the safe position.

Possible causes: Remote station on bus out of order, bus connection interrupted (e.g. cable, repeater, switch).

Several simultaneous errors

Even if several errors are present simultaneously on one channel, only the error handling for the first detected error is performed. Only after this error has been confirmed by resetting it to OK (alarm reset) can another error be detected.

Fire damper (Motorized_SafetyClose)

Depending on Alarm-Reset, Fire-Position, ActuDrive_1...2 and the error state the relay is switched as follows (evaluation from top to bottom)

others	ActuDrive_1...2	AlarmCode_1...2	Relay_1...2
Alarm-Reset	open (1)	OK (1)	On
Fire-Position	any	any	Off
-	any	Runtime_Error (3)	Off
	any	Update_Error (5)	Off
	any	Manipulation (4)	Off
	open (1)	OK (1)	On
	close (2)	OK (1)	Off

Initialization after power on / reset:

ActuDrive is set to open. AlarmCode is set to OK. The alarm reset starts to interrupt the self-retaining over fire position in safe state. It ends when the normal position is reached or in case of an error.

Smoke extraction flap (Motorized_SafetyOpen)

Depending on Alarm-Reset, Fire-Position, ActuDrive_1...2 and the error state the relay is switched as follows (evaluation from top to bottom)

others	ActuDrive_1...2	AlarmCode_1...2	Relay_1...2
Alarm-Reset	close (2)	OK (1)	Off
Fire-Position	any	any	On
-	any	Runtime_Error (3)	On
	any	Update_Error (5)	On
	any	Manipulation (4)	Off
	open (1)	OK (1)	On
	close (2)	OK (1)	Off

Initialization after power on / reset:

ActuDrive is set to close. AlarmCode is set to OK. The alarm reset starts to interrupt the self-retaining over fire position in safe state. It ends when the normal position is reached or in case of an error.

Fire damper (Motor_SafetyClose_2)

Depending on Alarm-Reset, Fire-Position, ActuDrive_1...2 and the error state the relay is switched as follows (evaluation from top to bottom)

others	ActuDrive_1...2	AlarmCode_1...2	Relay_1...2
Alarm-Reset	open (1)	OK (1)	On
Fire-Position	any	any	Off
-	any	Runtime_Error (3)	Off
	any	Update_Error (5)	Off
	any	Manipulation (4)	Off
	open (1)	OK (1)	On
	close (2)	OK (1)	Off

When controlling via ActuDrive, the last and first lines apply.

The fire position (ActuPos = open, running) is then not reported as an alarm.

Initialization after power on / reset:

ActuDrive is set to open. AlarmCode is set to OK. The alarm reset starts to interrupt the self-retaining over fire position in safe state. It ends when the normal position is reached or in case of an error.

Smoke extraction flap (Motor_SafetyOpen_2)

Depending on Alarm-Reset, Fire-Position, ActuDrive_1...2 and the error state the relay is switched as follows (evaluation from top to bottom)

others	ActuDrive_1...2	AlarmCode_1...2	Relay_1...2
Alarm-Reset	close (2)	OK (1)	Off
Fire-Position	any	any	On
-	any	Runtime_Error (3)	On
	any	Update_Error (5)	On
	any	Manipulation (4)	Off
	open (1)	OK (1)	On
	close (2)	OK (1)	Off

When controlling via ActuDrive, the last and first lines apply.

The fire position (ActuPos = open, running) is then not reported as an alarm.

Initialization after power on / reset:

ActuDrive is set to close. AlarmCode is set to OK. The alarm reset starts to interrupt the self-retaining over fire position in safe state. It ends when the normal position is reached or in case of an error.

Damper without motor (LimitSwitch...)

The relay is permanently switched off.

Operating mode Input_Logic_Control

In this operating mode the digital inputs are logically linked with the relay outputs.

There are two basic functions:

- Impulse switch function
- SPST switch function

The two functions are mutually exclusive. Therefore, the device automatically prevents the functions from being mixed up.

The relays can also be controlled via the toggle switches. In this case the switches have priority.

With the impulse switch function, the default setting of the respective relay (holding register RelayDefault) applies after switching on the device.

At SPST switching function, the status of the assigned inputs always applies.

If the connection monitoring (holding register BusTimeout) expires, there is **no** change to the default setting of the respective relay.

Impulse switch function

Here, a 0 to 1 change at one or more inputs causes the relay(s) to change the current state. Each 0 to 1 change toggle the state of the respective relay output, regardless of whether one or more inputs are selected to switch the relay.

SPST switch function

Here the relay output follows one or more inputs, that means the relay output has the same status as the assigned inputs:

Input = 0 → Relay OFF

Input = 1 → Relay ON

If several inputs are assigned to a relay, there is an OR link, that means as long as at least one assigned input is 1, the relay is switched on and only if all assigned inputs are 0 the relay switched off.

If a fire damper operating mode is set for a relay, the inputs assigned to the relay (see fire damper operating mode) are no longer available for the logic control of the other relay and are no longer considered and are automatically deactivated by the device.

Modbus Function "43 /14 (0x2B / 0x0E) Read Device Identification"

Request

Read Device ID code:	0x01
Object ID	0x00

Response

Device ID code	0x01	
Conformity level	0x01	
More follows	0x00	
Next object ID	0x00	
Number of objects	0x03	
Object ID	0x00	
Object Length	0x11	
Object Value	"METZ CONNECT GmbH"	
Object ID	0x01	
Object Length	0x09	0x0E
Object Value	"MR-DIO4/2"	"MR-DIO4/2IP65"
Object ID	0x02	
Object Length	0x04	
Object Value	"V2.0"	

MR-TP

I/O commands

Modbus Function "02 (0x02) Read Discrete Inputs"

Request

Valid Input Starting Address	0 .. 15
Valid Quantity of Inputs	1 .. 16

Response

Byte Count	1..2
Input Status	Bit0 .. Bit15

Information

Discrete Input 0-5:	switching status of the digital inputs, 0: OFF, 1: ON
Discrete Input 6-7:	feedback of transistor outputs, 0: OFF, 1: ON
Discrete Input 8-9:	feedback of switching status of relay 1, 0: Off, 2: level 1 (open), 3: level 2 (close)
Discrete Input 10-11:	Cause of the switching status of relay 1, for sunblind mode see table of priorities, otherwise 3: trigger switch, 0: Modbus coils
Discrete Input 12-13:	feedback of switching status of relay 2, 0: OFF, 2: level 1 (open), 3: level 2 (close)
Discrete Input 14-15:	Cause of the switching status of relay 2, for sunblind mode see table of priorities, otherwise 3: trigger switch, 0: Modbus coils

Modbus Function "04 (0x04) Read Input Registers"

Request

Valid Register Starting Address	0
Valid Quantity of Registers	1

Response

Byte Count	2
Values Register	Bit0 .. Bit15

Information

See information Discrete Input 0-15

Modbus Function "15 (0x15) Write Multiple Coils"

Request

Valid Coil Starting Address	0 .. 5
Valid Quantity of Outputs	1 .. 6
Valid Byte Count	1
Output Value	0 or 1 in Bit0 .. Bit5

Bit	Information								
0	0 = Status digital output 1 off								
	1 = Status digital output 1 on								
1	0 = Status digital output 2 off								
	1 = Status digital output 2 on								
2-3	Status relay 1 in "switch" mode: <table style="margin-left: 20px;"> <tr><td>0:</td><td>relay contact 11-14-24 open</td></tr> <tr><td>1:</td><td>relay contact 11-14-24 open</td></tr> <tr><td>2:</td><td>relay contact 11-14 closed</td></tr> <tr><td>3:</td><td>relay contact 11-24 closed</td></tr> </table>	0:	relay contact 11-14-24 open	1:	relay contact 11-14-24 open	2:	relay contact 11-14 closed	3:	relay contact 11-24 closed
0:	relay contact 11-14-24 open								
1:	relay contact 11-14-24 open								
2:	relay contact 11-14 closed								
3:	relay contact 11-24 closed								
4-5	Status relay 2 in "switch" mode: <table style="margin-left: 20px;"> <tr><td>0:</td><td>relay contact 31-34-44 open</td></tr> <tr><td>1:</td><td>relay contact 31-34-44 open</td></tr> <tr><td>2:</td><td>relay contact 31-34 closed</td></tr> <tr><td>3:</td><td>relay contact 31-44 closed</td></tr> </table>	0:	relay contact 31-34-44 open	1:	relay contact 31-34-44 open	2:	relay contact 31-34 closed	3:	relay contact 31-44 closed
0:	relay contact 31-34-44 open								
1:	relay contact 31-34-44 open								
2:	relay contact 31-34 closed								
3:	relay contact 31-44 closed								

Response

Function Code, Starting Address, Quantity of Outputs

Modbus Function "03 (0x03) Read Holding Registers"

Request

Valid Register Starting Address	0 .. 7 or 66
Valid Quantity of Registers	8 or 1

Response

Function Code, Byte Count, Register Values

Value Register 0:

Bits 0 – 5 according to the tables or the description above

Bits 6 – 15 have no function

Value Register 1:

Sunblind command (in Low-Byte)

The following registers are stored in the EEPROM.

The time constants have the unit 10 ms:

Value Register 2:

Operating mode (Low-Byte) and Flags (High-Byte)

Factory setting 1, storage in EEPROM

Value Register 3:

Bits 0-5 contain the basic setting for coils 0-5

Factory setting 0, storage in EEPROM

Value Register 4:

Time constant push-button short/long,

Unit 10 ms, factory setting 2 s, storage in EEPROM

Value Register 5:

Time constant short pulse,

Unit 10 ms, factory setting 0,5 s, storage in EEPROM

Value Register 6:

Time constant long pulse,

Unit 10 ms, factory setting 60 s, storage in EEPROM

Value Register 7:

Time constant rotating pulse (position the blades horizontally),

Unit 10 ms, factory setting 1 s, storage in EEPROM

Value Register 66

Time constant for connection monitoring

Unit 10 ms, factory setting 0 s, storage in EEPROM

Modbus Function "06 (0x06) Write Single Register"

Request

Register Address

0 - 7 or 66

Register Value

according to tables or descriptions above and below

Response

Echo of the request

Modbus Function "16 (0x10) Write Multiple Registers"

Request

Valid Register Starting Address

0 – 7 or 66

Valid Quantity of Registers

1 – 8

Byte Count

2 x Quantity of registers

Registers Value

according to tables or descriptions above and below

Response

Function Code, Register Starting Address, Quantity of Registers

Operating modes

The operating mode is selected by using the low bits of the operating mode register. The high bits contain more flags for sunblind operation (sunblind 1 / 2).

In all operating modes, a pause of 0.5 seconds of the Off status is included between level 1 and level 2 when the relay outputs are switched.

Operating mode 0 (Modbus Off)

The digital inputs and transistor outputs are queried and controlled by the Modbus.

The relay outputs are only controlled via the built-in trigger switches.

Function of the trigger switches: Top = level 1, center = OFF, bottom = level 2.

Operating mode 1 (Switch 0-1-2)

The digital inputs and transistor outputs are queried and controlled by the Modbus.

The relay outputs are controlled by the Modbus or by the built-in trigger switches.

Function of the trigger switches: Top = OFF, center = level 1, bottom = level 2.

Operating mode 2 (Switch 1-0-2)

The digital inputs and transistor outputs are queried and controlled by the Modbus.

The relay outputs are controlled by the Modbus or by the built-in trigger switches.

Function of the trigger switches: Top = level 1, center = OFF, bottom = level 2.

Operating mode 3 (Sunblind 1)

Unused digital inputs and transistor outputs are queried and controlled by the Modbus.

The relay outputs and digital inputs are used to control 2 sunblinds.

Used for AC/DC motors with separate coils for opening and closing.

Relay contact 11: operating voltage for motor 1

Relay contact 14: motor and limit switch 1 for opening

Relay contact 24: motor and limit switch 1 for closing

Relay contact 31: operating voltage for motor 2

Relay contact 34: motor and limit switch 2 for opening

Relay contact 44: motor and limit switch 2 for closing

Operating push-buttons and switching contacts are connected to the digital inputs.

Input 1: open sunblind 1

Input 2: close sunblind 1

Input 3: optional wind contact (NC or NO contact)

Input 4: open sunblind 2

Input 5: close sunblind 2

Input 6: optional door contact (NC or NO contact)

Operating mode 4 (Sunblind 2)

Unused digital inputs and transistor outputs are queried and controlled by the Modbus. The relay outputs and digital inputs are used to control the sunblind. Used for a DC motor that changes its direction of movement with polarity.

- Relay contact 11: motor limit switches, open +, close –
- Relay contact 14: operating voltage +
- Relay contact 24: operating voltage –
- Relay contact 31: motor limit switches, open –, close +
- Relay contact 34: operating voltage –
- Relay contact 44: operating voltage +

Operating push-buttons and switching contacts are connected to the digital inputs.

- Input 1: open sunblind
- Input 2: close sunblind
- Input 3: optional wind contact (NC or NO contact)
- Input 6: optional door contact (NC or NO contact)

Sunblind operating modes

Function of the trigger switches:

top = level 1 / opening, center = OFF, bottom = level 2 / closing.

Priorities of relay control, value is returned with relay status		
Priority	Value	Description
Highest	3	Trigger switch in the device
	2	Wind and door contact
	1	Sunblind command
Lowest	0	Inputs for operating keys

When the optional wind contact is activated, the sunblind is opened. The activation of the wind contact has the same effect as the sunblind command 2. When the optional door contact is activated, the sunblind is prevented from closing.

Different operation modes and time constants can be set for the operation pushbuttons.

Flags in operating mode register for sunblind mode		
Bit	Value	Description
15	0	No wind contact at input 3
	1	Wind contact at input 3
14	0	Wind contact is NO contact
	1	Wind contact is NC contact
13	0	No door contact at input 6
	1	Door contact at input 6
12	0	Door contact is NO contact
	1	Door contact is NC contact
10-8	0-3	Short pulse starts with key press
	0	Short pulse ends after the time constant „Short“
	1	Short pulse ends after the minimum of time constant „Short“ and key press
	2	Short pulse ends after the maximum of time constant „Short“ and key press
	3	Short pulse ends with key press
	4	Short pulse starts at the end of key press, ends after the time constant „Short“
	7	Pulse lasts as long as key press
	0-4	Long pulse starts after time constant „pushbutton“, ends after time constant „Long“ and ends earlier in case of a short key press
7	No long pulse	

Simultaneous control of both sunblinds with the sunblind command register is possible via the bus. The command sequence begins as soon as the register content is changed.

Coding of the sunblind commands	
0	Normal operation, control by operating pushbuttons possible
1	Switch off relay, lock control by operation pushbuttons (lock)
2	Long pulse for opening, then lock
3	Long pulse for closing, then lock
4	Long pulse for closing, then rotating pulse (blades horizontal), then lock

Modbus Function "43 /14 (0x2B / 0x0E) Read Device Identification"**Request**

Read Device ID code:	0x01
Object ID	0x00

Response

Device ID code	0x01
Conformity level	0x01
More follows	0x00
Next object ID	0x00
Number of objects	0x03
Object ID	0x00
Object Length	0x11
Object Value	"METZ CONNECT GmbH"
Object ID	0x01
Object Length	0x05
Object Value	"MR-TP"
Object ID	0x02
Object Length	0x04
Object Value	"V1.2"

MR-AO4

I/O commands

Modbus Function "03 (0x03) Read Holding Registers"

Holding Register 0-3: output value of the outputs,
Signed Integer16,
Holding Register 4-7: basic settings of the output values

Request

Valid Register Starting Address 0..7 or 66
Valid Quantity of Registers 1..8 or 1

Response

Byte Count 2 x Quantity of Registers
Values Register 0..7 0x0000 to 0xFFFF (0x7FFF = 10.24 Volt)

Unit = $10.24V / 215 = 1V / 3200 = 0.3125 \text{ mV}$

Value Register 66

Time constant for communication monitoring.

Register Value = 0 (0x0000) there is no communication monitoring, all other values are for communication monitoring with a solution of 10 ms.

0x0000 to 0xFFFF => 0 to 655.35 seconds = 10.9 minutes

Modbus Function "06 (0x06) Write Single Register"

Request

Valid Register Address 0..7 or 66
Valid Value Register 0..7 0x0000 to 0xFFFF (0x7FFF = 10.24 Volt)
Valid Value Register 66 0x0000 to 0xFFFF
(0 to 655.35 seconds)

Response

Echo of the request

Modbus Function "16 (0x10) Write Multiple Registers"

Request

Valid Register Starting Address 0..7 or 66
Valid Quantity of Registers 1..8
Valid Byte Count 2 x Quantity of Registers (QoR)
Valid Value Register 0..7 QoR x 0x0000 to 0xFFFF (0x7FFF = 10.24 Volt)

Response

Function Code, Register Starting Address, Quantity of Registers

Modbus Function "43 /14 (0x2B / 0x0E) Read Device Identification"

Request

Read Device ID code:	0x01
Object ID	0x00

Response

Device ID code	0x01
Conformity level	0x01
More follows	0x00
Next object ID	0x00
Number of objects	0x03
Object ID	0x00
Object Length	0x11
Object Value	"METZ CONNECT GmbH"
Object ID	0x01
Object Length	0x06
Object Value	"MR-AO4"
Object ID	0x02
Object Length	0x04
Object Value	"V1.4"

MR-AOP4

I/O commands

Modbus Function "01 (0x01) Read Coils"

Modbus Function "02 (0x02) Read Discrete Inputs"

Modbus Function "04 (0x04) Read Input Registers"

Request

Valid Starting Address 0 .. 3

Valid Quantities 1 .. 4

Response

Byte Count 1

Status Bit0 .. Bit3
 1 = manual mode
 0 = automatic mode

Modbus Function "03 (0x03) Read Holding Registers"

Holding Register 0-3: output values of the outputs,
Signed Integer16,

Holding Register 4-7: basic settings of the output values

Request

Valid Register Starting Address 0..7 or 66

Valid Quantity of Registers 1..8 or 1

Response

Byte Count 2 x Quantity of Registers

Values Register 0..7 0x0000 to 0xFFFF (0x7FFF = 10.24 Volt)

Unit = $10.24V / 215 = 1V / 3200 = 0.3125 \text{ mV}$

Value Register 66

Time constant for communication monitoring.

Register Value = 0 (0x0000) there is no communication monitoring, all other values are for communication monitoring with a resolution of 10 ms.

0x0000 to 0xFFFF => 0 to 655.35 seconds = 10.9 minutes

Modbus Function "06 (0x06) Write Single Register"

Request

Valid Register Address 0..7 or 66

Valid Value Register 0..7 0x0000 to 0xFFFF (0x7FFF = 10.24 Volt)

Valid Value Register 66 0x0000 to 0xFFFF
 (0 to 655.35 seconds)

Response

Echo of the request

Modbus Function "16 (0x10) Write Multiple Registers"

Request

Valid Register Starting Address	0..7 or 66
Valid Quantity of Registers	1..8
Valid Byte Count	2 x Quantity of Registers (QoR)
Valid Value Register 0..7	QoR x 0x0000 to 0xFFFF (0x7FFF = 10.24 Volt)

Response

Function Code, Register Starting Address, Quantity of Registers

Modbus Function "43 /14 (0x2B / 0x0E) Read Device Identification"

Request

Read Device ID code:	0x01
Object ID	0x00

Response

Device ID code	0x01
Conformity level	0x01
More follows	0x00
Next object ID	0x00
Number of objects	0x03
Object ID	0x00
Object Length	0x11
Object Value	"METZ CONNECT GmbH"
Object ID	0x01
Object Length	0x07
Object Value	"MR-AOP4"
Object ID	0x02
Object Length	0x04
Object Value	"V1.5"

MR-AI8

I/O commands

Modbus Function "04 (0x04) Read Input Registers"

Request

Valid Starting Address 0 .. 15
 Valid Quantities 1 .. 16 (1 .. 8 inputs)

Response

Byte Count 2 x Quantity o. R.
 Registers Values Quantity o. R. x 12 Bytes

Input	Register	Information
1	0-1	Measured values are supplied in 2 registers each (4 Bytes). Data type in the registers can be configured. (see register 16-23) Float value needs 2 registers (see floating point format) Signed in value is in the 1st register Signed in 0 fills the 2 nd register Value remains 0 until a measurement takes place Data types composed from 2 registers start at an even address
2	2-3	
3	4-5	
4	6-7	
5	8-9	
6	10-11	
7	12-13	
8	14-15	
1..8	70	Threshold exceedance state of all inputs, bit 0..7

Floating point format

Byte1 Bit7	Byte1 Bit6..0	Byte2 Bit7	Byte2 Bit6..0	Byte3	Byte4
Sign	Exponent	Exponent	Mantissa	Mantissa	Mantissa

Modbus-Function „02 (0x02) Read Discrete Inputs“

Request

Valid Starting Address 0 .. 7

Valid Quantities 1 .. 8

Response

Byte Count 2 x Quantity o. R.

Registers Values Quantity o. R. x 12 Bytes

Input	Register	Information
1	0	State of the threshold exceedance at associated input according to the configuration (bit 8)
2	1	
3	2	
4	3	
5	4	
6	5	
7	6	
8	7	

Coils

Modbus-Function “01 (0x01) Read Coils“

Modbus-Function “05 (0x05) Write Single Coil“

Address	Information
0	Unit of measurement for the standard temperature sensors, this setting applies to all inputs together. 0: Unit temperature °C 1: Unit temperature °F

Unit temperature

The readings can be reported in units of °C or °F in the input registers.

Holding register 68 or coil 0 is responsible for selection.

Selection of the temperature unit applies to all sensor types listed, but not to the interpolation table.

Configuration registers

Input circuit and measuring range, data type and value unit and the sensor characteristic for usual temperature sensors are set for the 8 inputs with the 8 configuration registers.

Modbus Function "03 (0x03) Read Holding Registers"

Modbus Function "06 (0x06) Write Single Registers"

Modbus Function "16 (0x10) Write Multiple Registers"

Holding Register 0-15:	Offset Register is added to the measured value in 2 succeeding registers, (Input 1 = Register 0 - 1) Float in both or Signed Integer 16 in the first one, same as for measured value.
Holding Register 16-23:	Configuration register (EEPROM), used to set measuring range, data type of the measured value (Float / Integer16), unit of the measured value and sensor characteristic (input 1 = register 16)
Holding Register 24-63:	Register for interpolation charts (EEPROM), alternately temperature and resistance, Float in 2 succeeding registers each.
Holding Register 68:	Unit temperature register (EEPROM), Bit 0: 0 = unit °C 1 = unit °F
Holding Register 70-101:	Switch-on and switch-off thresholds register (EEPROM), switch-on and switch-off threshold alternating, each in two following registers, Float in both or Signed Integer 16 in the first one, same as for measured value.

Configuration registers for voltage or resistance measurement

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0							THC	1	Range	Number					

Bit 15-9: reserved

Bit 8: THC: Threshold comparison
 0 Register = 1 if measured value > threshold,
 otherwise 0
 1 Register = 0 if measured value > threshold,
 otherwise 1

Bit 7: 0 = voltage or resistance

Bit 6-5: Range, defines input circuit or measuring range
 0 0 voltage 0 to 10 V, factory setting
 0 1 voltage 0 to 10 V, Pullup 2k at 5 V
 1 0 resistance
 1 1 reserved

Bit 4-0: Number, defines presentation of the measured value
 For voltage measurement:
 0 measured value with data type float,
 unit = 1 V
 1 measured value with data type signed int,
 unit = $10.24 \text{ V} / 2^{15} = 1 \text{ V} / 3200$
 = 0.3125 mV
 2-31 reserved for other presentations
 For resistance measurement:
 0 measured value with data type float,
 unit = 1 Ohm
 1 measured value with data type signed int,
 unit = 0.1 Ohm (max. 3.2767 kΩ)
 2 measured value with data type signed int,
 unit = 1 Ohm (max. 32.767 kΩ)
 3 measured value with data type signed int,
 unit = 10 Ohm (max. 327.67 kΩ)
 4 measured value with data type signed int,
 unit = 100 Ohm (max. 3276,7 kΩ)
 5-31 reserved for other presentations

Configuration registers for temperature measurement

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0							THC	1	Number						Type

Bit 15-9: reserved

Bit 8: THC: Threshold comparison
 0 Register = 1 if measured value > threshold,
 otherwise 0
 1 Register = 0 if measured value > threshold,
 otherwise 1

Bit 7: 1 = temperature with sensor characteristic

Bit 6-1: Number, is used to distinguish between sensor and characteristic

0	Sensor PT100	(-50..150 °C)
1	Sensor PT500	(-50..150 °C)
2	Sensor PT1000	(-50..150 °C)
3	Sensor NI1000-TK5000	(-50..150 °C)
4	Sensor NI1000-TK6180	(-50..150 °C)
5	Sensor BALCO 500	(-50..150 °C)
6	Sensor KTY81-110	(-50..150 °C)
7	Sensor KTY81-210	(-50..150 °C)
8	Sensor NTC-1k8	(-50..150 °C)
9	Sensor NTC-5k	(-50..150 °C)
10	Sensor NTC-10k	(-50..150 °C)
11	Sensor NTC-20k	(-50..150 °C)
12	Sensor LM235	(-40..120 °C)
13	Sensor NTC-10k CAREL	(-50..110 °C)
14-55	Reserved for other sensors	
56-61	Use of the interpolation chart see below	
62-63	Reserved	

Bit 0: Data type of the measured value
 0 float, unit 1 °C
 1 signed int, unit 0.1 °C

Configuration registers to use the interpolation chart

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0							THC	1	7			Range	Intp	Type	

- Bit 15-9: reserved
- Bit 8:
 - THC: Threshold comparison
 - 0 Register = 1 if measured value > threshold,
 - otherwise 0
 - 1 Register = 0 if measured value > threshold,
 - otherwise 1
- Bit 7: 1 Temperature with sensor characteristic
- Bit 6-4: 7 Interpolation chart
- Bit 3-2: Range, defines input circuit or measuring range
 - 0 0 Voltage 0 to 10 V
 - 0 1 Voltage 0 to 10 V, Pullup 2k at 5 V
 - 1 0 Resistance
 - 1 1 Reserved
- Bit 1: Selection of interpolation
 - 0 Sensor characteristic is nearly linear
 - 1 Sensor characteristic is nearly exponential (For ex. NTC)
- Bit 0: Data type of the measured value
 - 0 float, unit 1 °C
 - 1 signed int, unit 0.1 °C

Configurations registers are shown above in a way to display the meaning of the individual bit. For the application it is more convenient if the register contents is displayed as a whole, see the following chart (Dec, Hex: **Low-Byte** of the register):

Dec	Hex	Measuring range voltage or resistance	Data type	Unit	Maximum
0	0x00	voltage 0 to 10 V	float	1 V	10.24 V
1	0x01		signed int	0.3125 mV	
32	0x20	voltage/pullup	float	1 V	10.24 V
33	0x21		signed int	0.3125 mV	
64	0x40	resistance	float	1 Ω	4 MΩ
65	0x41		signed int	0.1 Ω	3.2767 kΩ
66	0x42		signed int	1 Ω	32.767 kΩ
67	0x43		signed int	10 Ω	327.67 kΩ
68	0x44		signed int	100 Ω	3276.7 kΩ

Temperature measurement with data type float:

Dec	Hex	Sensor type	Data type	Unit	Range
128	0x80	Sensor PT100	float	1 °C	-50..150 °C
130	0x82	Sensor PT500			-50..150 °C
132	0x84	Sensor PT1000			-50..150 °C
134	0x86	Sensor NI1000-TK5000			-50..150 °C
136	0x88	Sensor NI1000-TK6180			-50..150 °C
138	0x8A	Sensor BALCO 500			-50..150 °C
140	0x8C	Sensor KTY81-110 NXP			-50..150 °C
142	0x8E	Sensor KTY81-210 NXP			-50..150 °C
144	0x90	Sensor NTC-1k8 Thermokon			-50..150 °C
146	0x92	Sensor NTC-5k Thermokon			-50..150 °C
148	0x94	Sensor NTC-10k Thermokon			-50..150 °C
150	0x96	Sensor NTC-20k Thermokon			-50..150 °C
152	0x98	Sensor LM235			-40..120 °C
154	0x9A	Sensor NTC-10k CAREL			-50..110 °C

Temperature measurement with data type signed int (register number is by 1 larger than above):

Dec	Hex	Sensor type	Data type	Unit	Range
129	0x81	Sensor PT100	signed int	0.1 °C	-50..150 °C
131	0x83	Sensor PT500			-50..150 °C
133	0x85	Sensor PT1000			-50..150 °C
135	0x87	Sensor NI1000-TK5000			-50..150 °C
137	0x89	Sensor NI1000-TK6180			-50..150 °C
139	0x8B	Sensor BALCO 500			-50..150 °C
141	0x8D	Sensor KTY81-110 NXP			-50..150 °C
143	0x8F	Sensor KTY81-210 NXP			-50..150 °C
145	0x91	Sensor NTC-1k8 Thermokon			-50..150 °C
147	0x93	Sensor NTC-5k Thermokon			-50..150 °C
149	0x95	Sensor NTC-10k Thermokon			-50..150 °C
151	0x97	Sensor NTC-20k Thermokon			-50..150 °C
153	0x99	Sensor LM235			-40..120 °C
155	0x9B	Sensor NTC-10k CAREL			-50..110 °C

Measurement with interpolation chart:

Dec	Hex	Measuring range	Data type	Interpolation
240	0xF0	Voltage 0 to 10 V	float	linear
241	0xF1		signed int	linear
242	0xF2		float	exponential
243	0xF3		signed int	exponential
244	0xF4	Voltage/Pullup	float	linear
245	0xF5		signed int	linear
246	0xF6		float	exponential
247	0xF7		signed int	exponential
248	0xF8	Resistance	float	linear
249	0xF9		signed int	linear
250	0xFA		float	exponential
251	0xFB		signed int	exponential

Registers 24-63 (0x18-0x3F) interpolation chart

This chart can be used to convert and linearize values for sensors without a characteristic already defined in the device. The chart contains up to 10 nodes of the sensor characteristic to interpolate between.

Example: transformation from resistance to temperature for temperature sensors.

Register contents is stored in the EEPROM.

The description refers to temperature sensors. Other sensors than temperature sensors (e.g. humidity) are also possible and it is also possible to measure voltage instead of resistance.

These properties can be set in the configuration register:

Measuring range	voltage voltage, pullup 2k at 5 V (for ex. for LM235) resistance (normal case with temperature sensors)
Interpolation	sensor characteristic is nearly linear sensor characteristic is nearly exponential (for NTCs)
Data type of measuring range	float (unit 1 °C) signed int (unit 0.1 °C)

Node	Registers Temperature	Registers Resistance
1	24-25	26-27
2	28-29	30-31
3	32-33	34-35
4	36-37	38-39
5	40-41	42-43
6	44-45	46-47
7	48-49	50-51
8	52-53	54-55
9	56-57	58-59
10	60-61	62-63

The nodes are filled beginning at the top of the chart, with a maximum of 10, and end with temperature = resistance = 0 if there are less nodes. Temperature and resistance values must be in ascending or descending order. So the combination 0,0 as a node is not allowed. Data type in the registers: float temperature, float resistance.

Switch-on and switch-off threshold


To enable digital evaluation (0 → 1) of an analogue measurement by a defined value, all analogue inputs can be compared with an adjustable threshold value (adjustable switch-on and switch-off threshold). A threshold register is assigned to each analogue input. This enables a simple evaluation of the analogue measured value if only the information is required whether a measured value is above or below a certain threshold value.

If the switch-on threshold is exceeded the associated threshold register contains 1 (configuration bit 8 = 0) or 0 (configuration bit 8 = 1) depending on the configuration. If the measured value falls below the switch-off threshold the register value is reset. In the evaluating device the threshold register can simply be checked for 0 or 1 to trigger the required action. The switch-on and switch-off threshold can be set individually for each input and the specification is made in the same unit as the analogue measured value itself. The relationship between the switch-on and switch-off threshold is shown below.

The register value changes as soon as the analogue value has reached the switch-on threshold. As long as the analogue value remains above the switch-off threshold, the register value is maintained. Only if the analogue value falls below the switch-off threshold, the register value is reset.

The possibility of setting a separate switch-on and switch-off threshold is to prevent the register value from jumping back and forth between 0 and 1 when the analogue value fluctuates around the threshold.

If this behaviour is not needed, set the switch-off threshold to the same value as the switch-on threshold.



Modbus Function "43 /14 (0x2B / 0x0E) Read Device Identification"

Request

Read Device ID code:	0x01
Object ID	0x00

Response

Device ID code	0x01
Conformity level	0x01
More follows	0x00
Next object ID	0x00
Number of objects	0x03
Object ID	0x00
Object Length	0x11
Object Value	"METZ CONNECT GmbH"
Object ID	0x01
Object Length	0x06
Object Value	"MR-AI8"
Object ID	0x02
Object Length	0x04
Object Value	"V1.8"

MR-CI4

I/O commands

Modbus Function "04 (0x04) Read Input Registers"

Input Registers	
Address	Information
0 – 3	Measured values of inputs 1-4, Data type Signed Integer16, Value ranges: Value 0 = 0 V ,... Value 32767 = 10.24 V Value 0 = 0 mA ,... Value 32767 = 20.48 mA Value 0 = 4 mA ,... Value 32767 = 20.38 mA
4	Status register Bit 0...7: Position of DIP switches 1...8 Bit value 0 = OFF Bit value 1 = ON Bit 8...11: Status of inputs 1...4 Bit value 0 = voltage < 2 V or current < 4 mA Bit value 1 = voltage ≥ 2 V or current ≥ 4 mA

Modbus Function "43 /14 (0x2B / 0x0E) Read Device Identification"

Request

Read Device ID code: 0x01
Object ID 0x00

Response

Device ID code 0x01
Conformity level 0x01
More follows 0x00
Next object ID 0x00
Number of objects 0x03
Object ID 0x00
Object Length 0x11
Object Value "METZ CONNECT GmbH"
Object ID 0x01
Object Length 0x06
Object Value "MR-CI4"
Object ID 0x02
Object Length 0x04
Object Value "V1.4"

MR-AIO4/2-IP

Modbus-Function

Functions to read and write registers, address ranges in brackets:

Read Input Registers (0 - 7)

Read Holding Registers (0 - 63, 65, 66, 68)

Write Multiple Registers (0 - 63, 65, 66, 68)

Write Single Register (16 - 23, 65, 66, 68)

Read Holding Registers (100 - 123, 130 - 143, 150 - 173, 180 - 193, 200 - 231)

Write Multiple Registers (100 - 123, 130 - 143, 150 - 173, 180 - 193, 200 - 231)

Datatype float

For the datatype float 2 registers each, i.e. 4 bytes, are needed.

Modbus follows the principle that for data with several bytes length, the highest value is transmitted first and the lowest value last (big endian).

If several registers are needed for one datatype, all of them should be read or written together in one command, so that the data is consistent.

The registers can also be accessed individually, but then the user has to make sure, that the data is consistent, e.g. with multiple queries.

Register address	Register + 0		Register + 1	
Bytes in sequence of transmission	Byte 1 High	Byte 2 Low	Byte 3 High	Byte 4 Low
Bit numbers	Bit 31-24	Bit 23-16	Bit 15-8	Bit 7-0
Bits of float values	Sign, Exp 7-1	Exp 0, Mant 22-16	Mant 15-8	Mant 7-0

Reference to a compatibility problem:

With float, 4 different sequences of bytes in the registers are common on the market.

Function block analog Output (AO1-AO2)

The MR-AIO4/2 has 2 analog outputs for voltage (0-10 V).

Depending on the configuration, the output values can be coded as floating point numbers (float OutF) or integers with 16 bit and sign (int16_t OutI).

Name	Modbus Holding Registers	Adr. AO1	Adr. AO2
OutI	Values of analog outputs, data type int16_t, range: value 0 = 0 Volt ,... value 32767 = 10,24 Volt	20	21
InitOutI	Default values of analog outputs, data type int16_t, factory default 0, storage in EEPROM	22	23
OutF	Values of analog outputs, data type float, unit %, range: value 0 % = 0 Volt ,... value 102,4 % = 10,24 Volt	138	188
InitOutF	Default values of analog outputs, data type float, factory default 0, storage in EEPROM	122	172
Switch	Selection of output value: 0: Modbus register OutI 1: Modbus register OutF 2: Output Y of respective PID controller factory default 0, storage in EEPROM	100 Bits 4 - 5	100 Bits 6 - 7

For information on how to select the output value, see also the chapter entitled "Interconnection of Function Blocks" at the end.

Function Block Bus Watchdog

The connection to the Modbus master can be monitored with a watchdog timer. The timer restarts with every valid message sent to the device. Only the device address is important, not the rest of the message content. If the master or the connection fails and the timer expires, the outputs are switched to their default setting (safe state) and the red LED lights up. With the time constant 0 the watchdog timer is inactive.

Name	Modbus Holding Registers	Adr.
------	--------------------------	------

Watchdog	Time constant of communication monitoring, data type uint16_t, resolution 10 ms, factory default 0, storage in EEPROM	66
----------	---	----

When the device is switched on and the watchdog timer expires, these registers are copied:

Default value	Actual value
InitOutI_1/2 →	OutI_1/2
InitOutF_1/2 →	OutF_1/2
InitW_1/2 →	W_1/2

Function block analog-Input (AI1-AI4)

Overview


The MR-AIO4/2 has 4 universal analog inputs

- for voltage measurement (0 V - 11.5 V)
- and resistance measurement (40 Ohm - 4 MOhm).

An analog/digital conversion takes about 0.2 seconds and measurements are taken alternately at the inputs. At each input the measurement is performed in intervals of about 1 second, but when changing the resistance measuring range the interval is longer because measurements are performed several times.

There are operating modes to calculate the temperature of common temperature sensors. The voltage or resistance measured value is converted into the temperature with a value table and interpolation. There are several fix programmed tables for common sensors and a free programmable table with up to 10 interpolation points.

An offset can be added to the measured value. With this an adaptation to the sensor and the supply line or a fine adjustment can be realized.



In1...In4	Analog inputs
Mux	input switch
ADC	Analog/Digital Converter

- Volt/Ohm voltage/resistance calculation
- Interp Interpolation with value tables
- Sum Addition of an offset
- ConstTable Value tables for standard sensors
- Modbus register:
- Config Configuration Register
- Input Measured Value Register
- Offset Offset register
- VarTable Value table for own sensor type

Modbus register

Configuration data is retained in the devices even in the event of a power failure. They are stored in an EEPROM and are marked accordingly below.

Depending on the configuration, measured values can be coded as floating point numbers (float) or integers with 16 bits and sign (int16_t).

Name	Modbus Input Registers (Read-Only)	Adr. AI1	Adr. AI2	Adr. AI3	Adr. AI4
Input	Measured value in 2 consecutive registers, float in both or int16_t in first	0	2	4	6

Name	Modbus Holding Registers	AI	Adr.
Offset	Offset register, is added to measured value, in 2 consecutive registers, float in both or int16_t in first, same as measured value, factory default 0, storage in EEPROM	AI1	0
		AI2	2
		AI3	4
		AI4	6
-	Freely usable registers, factory default 0, storage in EEPROM	-	8 - 15
Config	Configuration register, used to select measuring range, data type of measured value (float / int16_t), unit of measured value and sensor characteristic, factory default 0 (Voltage 0-10V, float), storage in EEPROM	AI1	16
		AI2	17
		AI3	18
		AI4	19
VarTable	Variable lookup table used for interpolation, alternately temperature and resistance, float in 2 consecutive registers each, factory default 0, storage in EEPROM	-	24 - 63
Unit	Unit of measurement for the standard temperature sensors,	-	68

temperature	<p>this setting applies to all inputs together</p> <p>0: Unit temperature °C</p> <p>1: Unit temperature °F</p> <p>factory default 0, storage in EEPROM</p>		
-------------	--	--	--

General information about the configuration register

The 4 configuration registers are used to set the input circuit and measuring range, data type and unit of the measured value and the sensor characteristic curve for common temperature sensors for the 4 inputs.

The register contents are stored in the EEPROM.

Configuration registers for voltage or resistance measuring

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
0								0	Range	Number						

Bit 15-8:

reserved

Bit 7:

0 = voltage or resistance range,

Bit 6-5:

defines input circuit or measuring range

0 0 voltage 0 to 10V

0 1 voltage 0 to 10V, pullup 2k at 5 V

1 0 resistance

1 1 reserved

Bit 4-0:

Number, defines the presentation of the measured value

For voltage measurement:

0 measured value with data type float, unit = 1V

1 measured value with data type signed int, unit = $10.24V/2^{15} = 1V/3200 = 0.3125mV$

2-31 reserved for other presentations

For resistance measurement:

0 measured value with data type float, unit = 1 Ohm

1 measured value with data type signed int, unit = 0.1 Ohm (max. 3.2767 kOhm)

2 measured value with data type signed int, unit = 1 Ohm (max. 32.767 kOhm)

3 measured value with data type signed int, unit = 10 Ohm (max. 327.67 kOhm)

- 4 measured value with data type signed int, unit = 100 Ohm (max. 3276.7 kOhm)
- 5-31 reserved for other presentations

Configuration registers for temperature measurement

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0								1	Number						Type

Bit 15-8:

reserved

Bit 7:

1 = temperature with sensor characteristic

Bit 6-1:

Number, is used to distinguish sensor and measuring range

0 Sensor PT100 (-50..150°C)

1 Sensor PT500 (-50..150°C)

2 Sensor PT1000 (-50..150°C)

3 Sensor NI1000-TK5000 (-50..150°C)

4 Sensor NI1000-TK6180 (-50..150°C)

5 Sensor BALCO 500 (-50..150°C)

6 Sensor KTY81-110 (-50..150°C)

7 Sensor KTY81-210 (-50..150°C)

8 Sensor NTC-1k8 (-50..150°C)

9 Sensor NTC-5k (-50..150°C)

10 Sensor NTC-10k (-50..150°C)

11 Sensor NTC-20k (-50..150°C)

12 Sensor LM235 (-40..120°C)

13 Sensor NTC-10k CAREL (-50..110°C)

14-55 reserved for other sensors

56-61 use of the interpolation chart see below

62-63 reserved

Bit 0:

Data type of the measuring range

0 float, Unit 1°C

1 signed int, Unit 0.1°C

Configuration registers to use the interpolation chart

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0								1	7			Range		Intp	Type

- Bit 15-8: reserved
- Bit 7: 1 temperature with sensor characteristic
- Bit 6-4: 7 interpolation chart
- Bit 3-2: Range, defines input circuit or measuring range
 - 0 0 voltage 0 to 10V
 - 0 1 voltage 0 to 10V, pullup 2k at 5 V
 - 1 0 resistance
 - 1 1 reserved
- Bit 1: Selection of interpolation
 - 0 sensor characteristic is nearly linear
 - 1 sensor characteristic is nearly exponential (for ex. NTC)
- Bit 0: Data type of the measured value
 - 0 float, unit 1°C
 - 1 signed int, unit 0.1°C

Configurations registers are shown above in a way to display the meaning of the individual bit. For the application it is more convenient if the register contents is displayed as a whole, see the following chart

Dez	Hex	Measuring range Voltage or resistance:	Data type	Unit	Maximum
0	0x00	Voltage 0 to 10V	float	1 V	10.24 V
1	0x01		signed int	0.3125 mV	
32	0x20	Voltage/Pullup	float	1 V	10.24 V
33	0x21		signed int	0.3125 mV	
64	0x40	Resistance	float	1 Ohm	4 MOhm
65	0x41		signed int	0.1 Ohm	3.2767 kOhm
66	0x42		signed int	1 Ohm	32.767 kOhm
67	0x43		signed int	10 Ohm	327.67 kOhm
68	0x44		signed int	100 Ohm	3276.7 kOhm

Temperature measurement with data type float:

Dez	Hex	Measuring range	Data type	Unit	Maximum
128	0x80	Sensor PT100	float	1°C	-50..150°C
130	0x82	Sensor PT500			-50..150°C
132	0x84	Sensor PT1000			-50..150°C
134	0x86	Sensor NI1000-TK5000			-50..150°C
136	0x88	Sensor NI1000-TK6180			-50..150°C
138	0x8A	Sensor BALCO 500			-50..150°C
140	0x8C	Sensor KTY81-110 NXP			-50..150°C
142	0x8E	Sensor KTY81-210 NXP			-50..150°C
144	0x90	Sensor NTC-1k8 Thermokon			-50..150°C
146	0x92	Sensor NTC-5k Thermokon			-50..150°C
148	0x94	Sensor NTC-10k Thermokon			-50..150°C
150	0x96	Sensor NTC-20k Thermokon			-50..150°C
152	0x98	Sensor LM235			-40..120°C
154	0x9A	Sensor NTC-10k CAREL			-50..110°C

Temperature measurement with data type signed int (register number is by 1 larger then above):

Dez	Hex	Measuring range	Data type	Unit	Maximum
129	0x81	Sensor PT100	signed int	0.1°C	-50..150°C
131	0x83	Sensor PT500			-50..150°C
133	0x85	Sensor PT1000			-50..150°C
135	0x87	Sensor NI1000-TK5000			-50..150°C
137	0x89	Sensor NI1000-TK6180			-50..150°C
139	0x8B	Sensor BALCO 500			-50..150°C
141	0x8D	Sensor KTY81-110 NXP			-50..150°C
143	0x8F	Sensor KTY81-210 NXP			-50..150°C
145	0x91	Sensor NTC-1k8 Thermokon			-50..150°C
147	0x93	Sensor NTC-5k Thermokon			-50..150°C
149	0x95	Sensor NTC-10k Thermokon			-50..150°C
151	0x97	Sensor NTC-20k Thermokon			-50..150°C
153	0x99	Sensor LM235			-40..120°C
155	0x9B	Sensor NTC-10k CAREL			-50..110°C

Measurement with interpolation chart:

Dez	Hex	Measuring range	Data type	Interpolation
240	0xF0	Voltage 0 to 10V	float	linear
241	0xF1		signed int	linear
242	0xF2		float	exponential
243	0xF3		signed int	exponential
244	0xF4	Voltage/Pullup	float	linear
245	0xF5		signed int	linear
246	0xF6		float	exponential
247	0xF7		signed int	exponential
248	0xF8	Resistance	float	linear
249	0xF9		signed int	linear
250	0xFA		float	exponential
251	0xFB		signed int	exponential

Registers 24-63 (0x18-0x3F) interpolation chart

This chart can be used to convert and linearize values for sensors without a characteristic already defined in the device. The chart contains up to 10 nodes of the sensor characteristic to interpolate between.

Example: transformation from resistance to temperature for temperature sensors.

Register contents is stored in the EEPROM.

The description refers to temperature sensors. Other sensors than temperature sensors (e.g. humidity) are also possible and it is also possible to measure voltage instead of resistance.

These properties can be set in the configuration register:

Measuring range	voltage voltage, pullup 2k at 5 V (for ex. for LM235) resistance (normal case with temperature sensors)
Interpolation	sensor characteristic is nearly linear sensor characteristic is nearly exponential (for NTCs)
Data type of measuring range	float (unit 1 °C) signed int (unit 0.1 °C)

Node	Register	Register
	Temperature	Resistance
1	24-25	26-27
2	28-29	30-31
3	32-33	34-35
4	36-37	38-39
5	40-41	42-43
6	44-45	46-47
7	48-49	50-51
8	52-53	54-55
9	56-57	58-59
10	60-61	62-63

The nodes are filled beginning at the top of the chart, with a maximum of 10, and end with temperature = resistance = 0, if there are less nodes. Temperature and resistance values have to be in ascending or descending order. So the combination 0,0 as a node is not allowed. Data type in the registers: float temperature, float resistance.

Unit Temperature

The measured values can be output in the units °C or °F in the input registers.

Holding register 68 is responsible for the selection.

The selection of the temperature unit applies to all listed sensor types, but not to the interpolation table.

Function block PID controller (PID1-PID2)

General information on the controller type

The MR-AIO4/2 contains 2 PID controllers for applications for temperature control.

T1 filter

An ideal PID controller causes problems due to differentiation component:

- Quick changes at the input lead to restriction at the controller output and, thus, to non-linear behavior. (This may also be desired.)
- Noise and other interferences of the input measured values are intensified.

Therefore, real PID controllers are implemented with an additional T1 filter with smaller time constant T1 (PIDT1 controller). The filter can only be assigned to the D component or to P, I and D components together. For this controller, it applies only to the D component.

Differentiator input

The D component can be calculated from the difference of nominal value and actual value $\pm (X - W)$ or directly from the actual value $\pm X$ (this option can be switched). A quick change of the nominal value does not affect the output if the actual value is used directly.

Differential equation

This differential equation is used to define the function and variables:

$$Y = Y_p + Y_i + Y_{dt}$$

$$Y_p = F_p \cdot X_w$$

$$Y_i = F_p \cdot \frac{1}{T_i} \cdot \int_0^t (X_w) d\tau$$

$$Y_{dt} + T_1 \cdot \frac{d(Y_{dt})}{dt} = F_p \cdot T_d \cdot \frac{d(X_w d)}{dt}$$

with W = nominal value

X = actual value

X_w = difference $\pm (X - W)$

$X_w d$ = X_w or $\pm X$

Y = controller output

time

Y_i = integral component

Y_{dt} = differential component filtered

F_p = gain

T_i = integration time constant, reset time

T_d = differential time constant, derivative action

Y_p = proportional component T_1 = filter time constant

Output limitation

The I-share Y_i and the Y output are limited by the Y_{min} and Y_{max} constants. In addition, the Y output is limited by the values which can be changed during operation. PID1 controller has the input A_{min} which represents the lower limit for its Y output. PID2 controller has the B_{max} input which represents the upper limit for its Y output.

Dead range

This parameter can be used to prevent continuous small changes at the Y output. Otherwise, they can lead to wear of the valve controlled by the output. The Y output changes if the change is greater than $DeadR$ and remains constant in all other cases.


Manual operation

In the Automatic mode, the value at the Y output is also constantly saved in $ManY$ register. If the controller is switched to the Manual mode, it keeps its last value. By changing the $ManY$ in the Manual mode, the Y output is set to the new value. If the Manual mode is quit, the Y output starts controlling at the current value.

Activity

The controller can be set to activated or deactivated. If it is deactivated, the Y output is set to $DeactY$ permanently. If it is activated, the Y output starts its controlling activity with the $InitY$ value.

Controller structure



Controller algorithm

(Parameter):	if (PropF) else	$F_p = (Y_{max} - Y_{min}) / F_p_Xp$ $F_p = F_p_Xp$	
Block Dif:		$X_w = X - W$	
Block Ppi:	if (Action)	$Y_p = F_p * X_w$ $Y_p = -Y_p$	
Block Pdt:	if (InputD) else if (Action)	$Y_q = F_p * X$ $Y_q = F_p * X_w$ $Y_q = -Y_q$	
Block I:	if (Enable 0 -> 1) if (Manual 1 -> 0) if (Ti > 0) if (Yi < Ymin) if (Yi > Ymax) if (!Enable) if (Manual)	$Y_i = Y_{i_1}$ $Y_i = InitY - Y_p$ $Y_i = ManY - Y_p$ $Y_i = Y_i + Y_p * T_e / T_i$ $Y_i = Y_{min}$ $Y_i = Y_{max}$ $Y_i = 0$ $Y_i = 0$	(Start PID) (Auto PID)
Block DT:	if (Td > 0) if (T1 > 0) if (!Enable) if (Manual)	$Y_d = 0$ $Y_d = (Y_q - Y_{q_1}) * T_d / T_e$ $Y_{dt} = Y_d$ $Y_{dt} = Y_{dt_1} + (Y_d - Y_{dt_1}) * T_e / T_1$ $Y_{dt} = 0$ $Y_{dt} = 0$	
Block Sum:	if (Ys < Ymin) if (Ys > Ymax) if (EnAmin) if (EnBmax) if (Manual) if (!Enable) if (!Manual)	$Y_s = Y_p + Y_i + Y_{dt}$ $Y_s = Y_{min}$ $Y_s = Y_{max}$ if (Ys < Amin) $Y_s = Amin$ if (Ys > Bmax) $Y_s = Bmax$ $Y_s = ManY$ $Y_s = DeactY$ $ManY = Y_s$ if ($ Y - Y_s > DeadR$) $Y = Y_s$	(only PID1) (only PID2)

(Time Step Te): $Y_{i_1} = Y_i$, $Y_{q_1} = Y_q$, $Y_{dt_1} = Y_{dt}$

Modbus registers



The controller parameters belong to the data type float. They are saved permanently in EEPROM.

They can be accessed using the following Modbus registers.


Name	Configuration Registers, storage in EEPROM (Modbus Holding Registers)	Adr. PID1	Adr. PID2
Mode	Option Flags for Operating Mode:	101	151
.Enable	Activation signal of controller. 0: Controller is inactive 1: Controller is active (Default)	Bit 0	Bit 0
.PropF	The Proportional factor can be specified in two ways. 0: Amplification Fp (Default) 1: Range Xp	Bit 1	Bit 1
.Action	The difference $X_w = \pm (X - W)$ can be used directly or negated. 0: Difference used directly, $X_w = + (X - W)$ 1: Difference used negated, $X_w = - (X - W)$ (Default)	Bit 2	Bit 2
.InputD	The derivated part can be calculated from X_w or X . 0: D-Part calculated from $\pm X_w$ (Default) 1: D-Part calculated from $\pm X$	Bit 3	Bit 3
.EnAmin	Enable for minimum input Amin (only PID1). 0: Disable (Default) 1: Enable	Bit 4	---
.EnBmax	Enable for maximum input Bmax (only PID2). 0: Disable (Default) 1: Enable	---	Bit 4
.Manual	0: Automatic mode (Default) 1: Manual mode	Bit 5	Bit 5
Fp_Xp	Proportional factor specified in one of two ways: - Amplification Fp (Default 3, Unit % / °C) - Range Xp (Unit °C) Relation: $F_p * X_p = (Y_{max} - Y_{min})$	102	152
Ti	Integration time (Default 300, Unit s)	104	154
Td	Derivation time (Default 1, Unit s)	106	156
T1	Filter time (Default 10, Unit s)	108	158
Ymin	Lower limit of output Y (Unit %)	110	160
Ymax	Upper limit of output Y (Unit %)	112	162
DeadR	Dead range of output Y, Y changes in minimum steps of DeadR (Unit %)	114	164
DeactY	Y value when controller is inactive (Default 0, Unit %)	116	166
InitY	Y start value when controller is switched to active (Default 0, Unit %)	118	168

Name	Visualization / Control Registers (Modbus Holding Registers)	Adr. PID1	Adr. PID2
Yp	Proportional part (Unit %, Read Only)	130	180
Yi	Integral part (Unit %, Read Only)	132	182
Ydt	Derivate part, filtered (Unit %, Read Only)	134	184
ManY	Y value when using manual mode (Unit %)	142	192

Function block Linear mapping with limitation (LCL1-LCL4)

Description LCL1 - LCL2

The function block has the X input and Y output. Between two limits (X1, X2), the input values are shown on a linear map relative to the output values (Y1...Y2). Outside the limits, the output values are limited to Y1 or Y2.




Modbus registers

The parameters belong to the float data type. They are saved permanently in EEPROM. Separate holding registers for each function block LCL1...LCL2:

Name	Configuration Registers, storage in EEPROM (Modbus Holding Registers)	Adr. LCL1	Adr. LCL2
Y1	Point1, output Y (Default 0)	200	208
Y2	Point2, output Y (Default 100)	202	210
X1	Point1, input X (Default 0)	204	212
X2	Point2, input X (Default 100)	206	214

Description LCL3 - LCL4

The function block has the X input and Y output. Two points (X1, Y1) and (X2, Y2) define how the input values are mapped to the output values. The output values are limited to Y3 (minimum) or Y4 (maximum).




Modbus registers

The parameters belong to the float data type. They are saved permanently in EEPROM. Separate holding registers for each function block LCL1...LCL4:

Name	Configuration Registers, storage in EEPROM (Modbus Holding Registers)	Adr. LCL3	Adr. LCL4
Y1	Point1, output Y (Default 0)	216	228
Y2	Point2, output Y (Default 100)	218	230
X1	Point1, input X (Default 0)	220	232
X2	Point2, input X (Default 100)	222	234
Y3	Lower limit of output Y (Default 0)	224	236
Y4	Upper limit of output Y (Default 100)	226	238

Wiring the function blocks

Overview



Depending on the operating mode, nominal value and actual value can originate from the analog inputs. These inputs provide values in Volts, Ohms or degrees of Celsius. If the function block Linear conversion / limit or freely programmable interpolation table is used in the analog input, adjustment to other value ranges and units can be performed at the controller input.

If the controller nominal value is set via Modbus, there are 2 separate registers:

- The initial nominal value InitW_1/2 is saved permanently in EEPROM.
- The nominal value W_1/2 can be written or read out anytime using Modbus.

The output value for an analog output can originate from the registers OutI and OutF or from a PID controller. After each selection, the output value is reported in OutL and OutF.

When switching on the device and after the Watchdog timer has elapsed, these registers are copied:

Default setting	Current value
InitOutI_1/2 →	OutI_1/2
InitOutF_1/2 →	OutF_1/2
InitW_1/2 →	W_1/2

Modbus registers

One PID controller is assigned to one output and 2 inputs respectively.

A register contains fields for the switches shown in the figure.

Other registers contain the nominal value and output value.

Name	Configuration Registers, storage in EEPROM (Modbus Holding Registers)	Adr.
Switch	Selection of signals (Default 0)	100
.SW1	Selection of setpoint W for controller PID1: 0: Analog input In2 1: Analog input In2 with Linear Conversion / Limit LCL1 2: Modbus register W_1 In each selection the setpoint W is shown in Modbus register W_1.	Bits 0 – 1
.SW2	Selection of setpoint W for controller PID2: 0: Analog input In4 1: Analog input In4 with Linear Conversion / Limit LCL2 2: Modbus register W_2 In each selection the setpoint W is shown in Modbus register W_2.	Bits 2 – 3
.SW3	Selection of output value for analog output Out1: 0: Modbus register OutI_1 (int16_t) 1: Modbus register OutF_1 (float %) 2: Output value Y of controller PID1 In each selection the output value is shown in both Modbus registers.	Bits 4 – 5
.SW4	Selection of output value for analog output Out2: 0: Modbus register OutI_2 (int16_t) 1: Modbus register OutF_2 (float %) 2: Output value Y of controller PID2 In each selection the output value is shown in both Modbus registers.	Bits 6 – 7
InitW_1	Initial setpoint for controller PID1 (Default 0, Unit °C)	120
InitW_2	Initial setpoint for controller PID2 (Default 0, Unit °C)	170

Name	Visualization /Control Registers (Modbus Holding Registers)	Adr.
W_1	Setpoint W for controller PID1 (Unit °C)	136
W_2	Setpoint W for controller PID2 (Unit °C)	186
Amin	Minimum value for PID1 (Unit %, Read only)	140
Bmax	Maximum value for PID2 (Unit %, Read only)	190

Modbus Function "43 /14 (0x2B / 0x0E) Read Device Identification"

Request

Read Device ID code: 0x01
 Object ID 0x00

Response

Device ID code 0x01
 Conformity level 0x01
 More follows 0x00
 Next object ID 0x00
 Number of objects 0x03
 Object ID 0x00
 Object Length 0x11
 Object Value "METZ CONNECT GmbH"
 Object ID 0x01
 Object Length 0x09
 Object Value "MR-AIO4/2"
 Object ID 0x02
 Object Length 0x04
 Object Value "V1.4"

MR-SM3

I/O commands

Modbus Function "03 (0x03) Read Holding Registers" (R)

Modbus Function "04 (0x04) Read Input Registers" (R)

Modbus Function "06 (0x06) Write Single Register" (W)

Modbus Function "16 (0x10) Write Multiple Registers" (W)

Information

The Input Registers 0 and 31 to 38 are only relevant for production process.

Read Holding Registers (0 - 127, 256 – 383, 512 – 639, 768 - 895)

Read Input Registers (0 - 127, 256 – 383, 512 – 639, 768 - 895)

Write Single Register (0, 31, 32, 42 to 59, 65, 120 - 127)

Write Multiple Registers (42 to 59, 65, 120 - 127)

Input Register, Holding Register			
Register Address	Description	Data type	Solution Unit
0	Calibration command Is only used during production.	Unsigned R / W	-
1 2 3	Voltage 1 RMS Voltage 2 RMS Voltage 3 RMS	Unsigned R	0.1 V
4 5 6	Current 1 RMS Current 2 RMS Current 3 RMS	Unsigned R	0.01 A
7 8 9	Voltage 1 Peak value Voltage 2 Peak value Voltage 3 Peak value	Unsigned R	0.1 V
10 11 12	Current 1 Peak value Current 2 Peak value Current 3 Peak value	Unsigned R	0.01 A
13 14 15	Frequency 1 Frequency 2 Frequency 3	unsigned	0.01 Hz

16	Active power 1	Signed	1 W
17	Active power 2	R	
18	Active power 3		
19	Apparent power 1	Unsigned	1 VA
20	Apparent power 2	R	
21	Apparent power 3		
22	Active power 1	Signed	0.1 W
23	Active power 2	R	
24	Active power 3		
25	Apparent power 1	Unsigned	0.1 VA
26	Apparent power 2	R	
27	Apparent power 3		
28	Reactive power 1	Signed	0.1 VAR
29	Reactive power 2		
30	Reactive power 3		
31	Calibration voltage	Unsigned R / W	0.01 V
32	Calibration current	Unsigned R / W	0.001 A
33	Calibration status flags 1	Bits 0-15	-
34	Calibration status flags 2		
35	Calibration status flags 3		
36	Calibration status flags 1	Bits 16-31	-
37	Calibration status flags 2		
38	Calibration status flags 3		
39	Reactive power 1	signed	1 VAR
40	Reactive power 2		
41	Reactive power 3		
42-43	Active energy 1	unsigned long R / W	1 Wh
44-45	Active energy 2		
46-47	Active energy 3		
	Counts absorbed active energy increasing order and generated active energy decreasing order Begins after device power-on with the value 0.		
48-49	Reactive energy 1	unsigned long R / W	1 VARh
50-51	Reactive energy 2		
52-53	Reactive energy 3		
	Counts absorbed active energy increasing order and generated active energy decreasing order Begins after device power-on with the value 0.		

54 55 56	Transformation factor voltage 1 Values 1 to 254 Transformation factor voltage 2 Transformation factor voltage 3 Non-volatile storage in EEPROM. Has only an effect on the registers of energy or on the registers with data type float.	unsigned R / W	-
57 58 59	Transformation factor Current 1 Values 1 to 254 Transformation factor Current 2 Transformation factor Current 3 Non-volatile storage in EEPROM. Has only an effect on the registers of energy or on the registers with data type float.	unsigned R / W	-
60 61 62	Phase angle 1 Phase angle 2 Phase angle 3	signed R	1 °
65	Codes for bit rate and parity Factory setting 19200 bits, even parity. Non-volatile storage in EEPROM. Bit 0-3: Code for bit rate. Code 0x01 0x02 0x03 0x04 0x05 0x06 0x07 0x08 Bit/s 1200 2400 4800 9600 19200 38400 57600 115200 Bit 4-7: Code for parity. Code 0x10 0x20 0x30 Parity Even Odd None Bit 8-15: Value 0x53 enables changes with the commands Write-Single/Multiple-Registers. Then write this register as the only one.	unsigned R / W	-
66-67 68-69 70-71	Active power 1 Active power 2 Active power 3	float R	W
72-73 74-75 76-77	Apparent power 1 Apparent power 2 Apparent power 3	float R	VA
78-79 80-81 82-83	Reactive power 1 positive at inductive load Reactive power 2 negative at capacitive load Reactive power 3	float R	VAR

84-85	Voltage 1 RMS.	float	V
86-87	Voltage 2 RMS		
88-89	Voltage 3 RMS	R	
90-91	Current 1 RMS	float	A
92-93	Current 2 RMS		
94-95	Current 3 RMS	R	
96-97	Voltage 1 Peak value	float	V
98-99	Voltage 2 Peak value		
100-101	Voltage 3 Peak value	R	
102-103	Current 1 Peak value	float	A
104-105	Current 2 Peak value	R	
106-107	Current 3 Peak value		
108-109	Power factor 1	float	-
110-111	Power factor 2	R	
112-113	Power factor 3		
114	Angle of phase 2 to 2	signed	0.1 °
115	Angle of phase 3 to 2		
116	Angle of phase 2 to 3	R	
	Used only with three-phase current, specified values -120° at normal direction of rotation (negative, right) 120° at reverse direction of rotation (positive, left)		
117	Voltage value of positive sequence	unsigned	0.1 V
118	Voltage value of negative sequence		
119	Voltage value of zero sequence Values of the symmetrical components with three-phase current.	R	
120	Undervoltage tolerance Effective voltage = 230 V * (100 % – tolerance_undervoltage) / 100 % Nonvolatile storage in EEPROM.	unsigned R / W	%

121	<p>Overvoltage tolerance Effective voltage = $230 \text{ V} * (100 \% + \text{tolerance_overvoltage}) / 100 \%$ Nonvolatile storage in EEPROM.</p>	<p>unsigned R / W</p>	%
122	<p>Asymmetry tolerance (negative sequence) Voltage_negative_system / voltage_positive_sequence = tolerance_asymmetry / 100 % Nonvolatile storage in EEPROM.</p>	<p>unsigned R / W</p>	%
123	<p>Asymmetry tolerance (zero sequence) Voltage_zero_sequence / voltage_positive_sequence = tolerance_asymmetry / 100 % Nonvolatile storage in EEPROM.</p>	<p>unsigned R / W</p>	%
124	<p>Initial setting of Enable bits of voltage monitoring Is copied to register 125 when the device is switched on. Nonvolatile storage in EEPROM.</p>	<p>unsigned R / W</p>	-
125	<p>Enable bits of voltage monitoring Each error bit in register 126 has one enable bit. Only if an enable bit is set, the respective error bit can be set. Recording of measured voltage values stops when error bits are set.</p>	<p>unsigned R / W</p>	-
126	<p>Error bits of voltage monitoring Bit 0-2: voltage drop 1-3 (< 25V) Bit 3-5: undervoltage 1-3 Bit 6-8: overvoltage 1-3 Bit 13: asymmetry (zero sequence) Bit 14: asymmetry (negative sequence) Bit 15: wrong direction of rotation The respective bit is automatically set in case of an error, it is not deleted when the error has been removed but has to be deleted via Modbus. It is also possible to set bits via Modbus.</p>	<p>unsigned R / W</p>	-
127	<p>Status of measured value recording Bit 0: recording (0) is running, (1) is stopped Bit 1: period of recording (0) 100ms, (1) 200ms</p>	<p>unsigned R R / W</p>	-

256-383	Recording of measured values voltage L1-N	signed R	0.1 V
512-639	Recording of measured values voltage L2-N		
768-895	Recording of measured values voltage L3-N		
	The wave shape of the three voltages can be determined with 128 recorded measured values of each phase. Recording of measured voltage values stops when error bits are set, so that the cause of error can later be determined on the basis of the wave shape.		

At a RMS voltage less than 25 V the values of voltage, current, frequency and power are transmitted as 0.

The registers are updated with new measured values once per second.

Special data types

For Modbus applies, that in case of data with a length of several Bytes the High Byte will be transmitted first and the Low Byte last (Big-Endian). Data types with a length of multiple registers are described below.

If a data type needs several registers they should be read or written all together in one command to assure consistency of data. Registers can be accessed individually but then the user has to assure that data are consistent, for example with multiple queries.

Data type unsigned long

This data type uses 2 registers each, that means 4 Bytes.

Register addresses	Register + 0		Register + 1	
Bytes in order of transmission	Byte 1 High	Byte 2 Low	Byte 3 High	Byte 4 Low
Bit numbers	Bit 31-24	Bit 23-16	Bit 15-8	Bit 7-0

Data type float

This data type uses 2 registers each, that means 4 Bytes.

Register addresses	Register + 0		Register + 1	
Bytes in order of transmission	Byte 1 High	Byte 2 Low	Byte 3 High	Byte 4 Low
Bit numbers	Bit 31-24	Bit 23-16	Bit 15-8	Bit 7-0
Bits of float value	Sign, Exp 7-1	Exp 0, Mant 22-16	Mant 15-8	Mant 7-0

Indication of a compatibility problem:

4 different orders of the bytes in the registers are used in the market for data type "Float".

Configuration of the terminal block contacts

1La, 2La, 3La	Phase supply
1Lb, 2Lb, 3Lb	Phase consumer
1N, 2N, 3N	Neutral lead

At the contacts of the neutral lead the supply and consumer should not only be connected via the PC board because otherwise the power loss in the device is getting too high. The two neutral lead terminal blocks have to be connected by an external bridge if both are used.

Modbus Function "43 /14 (0x2B / 0x0E) Read Device Identification"

Request

Read Device ID code:	0x01
Object ID	0x00

Response

Device ID code	0x01
Conformity level	0x01
More follows	0x00
Next object ID	0x00
Number of objects	0x03
Object ID	0x00
Object Length	0x11
Object Value	"METZ CONNECT GmbH"
Object ID	0x01
Object Length	0x06
Object Value	"MR-SM3"
Object ID	0x02
Object Length	0x04
Object Value	"V1.2"

MR-Multi I/O 12DI/7AI/2AO/8DO

I/O-commands

- Modbus-Function „01 (0x01) Read Coils“ (R)
- Modbus-Function „02 (0x02) Read Discrete Inputs“ (R)
- Modbus-Function „03 (0x03) Read Holding Registers“ (R)
- Modbus-Function „04 (0x04) Read Input Registers“ (R)
- Modbus-Function „05 (0x05) Write Coils“ (W)
- Modbus-Function „06 (0x06) Write Single Register“ (W)
- Modbus-Function „16 (0x10) Write Multiple Registers“ (W)

Information

Read Discrete Inputs	(0 - 15)
Read Coils	(0 - 47)
Write Multiple Coils	(0 - 47)
Write Single Coil	(0 - 47)
Read Input Registers	(0 - 99)
Read Holding Registers	(0 - 99)
Write Multiple Registers	(0 - 99)
Write Single Register	(0 - 99)

Function block Bus-Watchdog

The Modbus communication may be controlled by a watchdog timer. The timer restarts with every valid message, that was directed to the device. Only the devices address is relevant, not the rest of the message. If the bus master or the connection fails and the timer will elapse, the outputs switch to their default values (save state) and the red LED will shine. With the time constants value of 0 the watchdog timer is inactive.

Holding Registers	
Addr.	Description
66	Time constant of communication monitoring Data type uint16, resolution 10 ms Maximum value = 65535 = 655.35 seconds = 10.9 minutes Factory default 0 (watchdog inactive) Storage in EEPROM

While defining the time constant you have to respect several items, which effects how often the slave has to be addressed:

- Baudrate of the system
- Number of slaves
- Length of the messages of each slave
- Priorities while addressing the slaves
- Transmission errors cause timeouts and repetitions
- Capability and processor load of the master

Function block unit temperature

The measured values can be output in the units °C or °F in the input registers.

Holding register 68 or coil 32 is responsible for the selection.

The selection of the temperature unit applies to all listed sensor types, but not to the interpolation table.

Coils	
Addr.	Description
32	Unit of measurement for the standard temperature sensors, this setting applies to all inputs together. 0: Temperatur in °C 1: Temperatur in °F

Holding Registers	
Addr.	Description
68	Unit of measurement for the standard temperature sensors, this setting applies to all inputs together. 0: Unit temperature °C 1: Unit temperature °F Storage in EEPROM

Function block Digital Input

On each input a yellow LED shows the status.

Discrete Inputs	
Addr.	Description
0 - 10	Value of digital inputs 1...11
11	Value of digital input S0 (usable as counter input)
	Value 0: off, 1: on

Input Registers / Holding Registers	
Addr.	Description
70	Value of digital inputs
	Same as Discrete Inputs 0-15

Function block Digital Output

The relay outputs may be overdriven by push buttons, not the Photo-MOS outputs.

A long keystroke (> 1s) changes between automatic und manual operation.

A short keystroke (< 1s) changes in manual operation between Off and On.

On each output a yellow LED shows the status, a green LED shows if it is manual operation.

Coils	
Addr.	Description
0 - 3	Value of relay outputs 1...4
	Value 0: off, 1: on
4 - 7	Value of Photo-MOS outputs 1...4
	Value 0: off, 1: on
16 - 19	Operating mode of relay outputs 1...4 (read only)
	Value 0: automatic mode, 1: manual mode
	Storage in EEPROM

Holding Registers	
Addr.	Description
71	Value of digital outputs
	Same as Coils 0-15
72	Operating mode (automatic, manual) of digital outputs (read only)

	Same as Coils 16-31 Storage in EEPROM
73	Default values of digital outputs Factory default 0 Storage in EEPROM

Function block Analog Output

On each output a yellow LED shows with its brightness the outputs voltage.

Holding Registers	
Addr.	Description
74 - 75	Values of analog outputs O1...O2 Data type int16, Range: value 0 = 0 Volt ,... value 32767 = 10.24 Volt
78 - 79	Default values of analog outputs O1...O2 Data type int16, Factory default 0, Storage in EEPROM

Function block Analog Input


Overview

The inputs E1 to E6 universally serve for voltage measuring (0 to 11.5 V) and for resistance measuring (40 Ohm to 4 MOhm). The input I serves for current measuring (0 to 22 mA).

An analog to digital conversion takes about 0.2 seconds and measurements are taken alternatively at the inputs. A measurement is taken at each input with an interval of about 1.8 seconds, it takes a bit longer when the resistance measuring range is changed because several measurements are taken.

There are operating mode to calculate the temperature of standard temperature sensors. The measured voltage or resistance value is converted with a value chart and interpolation into the temperature. There are several pre-programmed charts for standard sensors and a freely programmable chart with up to 10 nodes.

An offset can be added to the measured value. This allows an adaptation to the sensor and the supply line or a fine tuning.



- E1...E6, I analog inputs, contacts E1 to E6 and I
- Mux input switch
- ADC analog-to-digital converter
- V/A/Ohm calculate voltage / current / resistance
- Interp interpolation with value charts
- Sum addition of an offset
- ConstTable value charts for standard sensors

Modbus registers:

- Config Configuration Register
- Input Measured Value Register
- Offset Offset Register
- VarTable Value chart for specific sensor type

Modbus register

The measured values may be configured as float or 16 bit integer with leading sign.

Input Registers			
Addr.	AI	Name	Description
0	E1	Input 1...7	Measured value 2 consecutive registers, float in both or int16_t in first.
2	E2		
4	E3		
6	E4		
8	E5		
10	E6		
12	I		

Holding Registers			
Addr.	AI	Name	Description
0 - 1	E1	Offset 1...7	Offset register The offset is added to the measured value. 2 consecutive registers, float in both or int16_t in first, same data type as measured value. Factory default 0. Storage in EEPROM.
2 - 3	E2		
4 - 5	E3		
6 - 7	E4		
8 - 9	E5		
10 - 11	E6		
12 - 13	I		
14 - 15	-		
16	E1	Config 1...7	Configuration register Number (see below), used to select the - measuring range, - data type of measured value (float / int16_t), - unit of measured value, - sensor characteristic. Factory default 0 (Voltage 0-10V, float). Storage in EEPROM.
17	E2		
18	E3		
19	E4		
20	E5		
21	E6		
22	I		
23	-		
24 - 27 28 - 31 32 - 35 ... 60 - 63	-	VarTable 1...10	Variable lookup table used for interpolation Alternately temperature and resistance (see below). Float in 2 consecutive registers each. Factory default 0. Storage in EEPROM.

Configuration registers

Input circuit and measuring range, data type and value unit and the sensor characteristic for usual temperature sensors are set for the 7 inputs with the 7 configuration registers. With the aid of the following charts the values of the registers are shown decimal and hexadecimal.

Voltage, Current or resistance:

Dec	Hex	Measuring range	Data type	Unit	Maximum
0	0x00	Voltage 0-10V	float	1 V	11.5 V
1	0x01		int16_t	0.3125 mV	10.24 V
0	0x00	Current 0-20mA	float	1 mA	22 mA
1	0x01		int16_t	0.625 μ A	20.48 mA
32	0x20	Voltage 0-10V	float	1 V	11.5 V
33	0x21	Pullup 2k Ω at 5V	int16_t	0.3125 mV	10.24 V
64	0x40	Resistance	float	1 Ω	4 M Ω
65	0x41		int16_t	0.1 Ω	3.2767 k Ω
66	0x42		int16_t	1 Ω	32.767 k Ω
67	0x43		int16_t	10 Ω	327.67 k Ω
68	0x44		int16_t	100 Ω	3276.7 k Ω

For voltage with type signed integer: $10.24V / 2^{15} = 1V / 3200 = 0.3125mV$

For current with type signed integer: $20.48mA / 2^{15} = 1mA / 1600 = 0.625\mu A$

Temperature measurement with data type float:

Dec	Hex	Measuring range	Data type	Unit	Range
128	0x80	Sensor PT100	float	1°C	-50..150°C
130	0x82	Sensor PT500			-50..150°C
132	0x84	Sensor PT1000			-50..150°C
134	0x86	Sensor NI1000-TK5000			-50..150°C
136	0x88	Sensor NI1000-TK6180			-50..150°C
138	0x8A	Sensor BALCO 500			-50..150°C
140	0x8C	Sensor KTY81-110 NXP			-50..150°C
142	0x8E	Sensor KTY81-210 NXP			-50..150°C
144	0x90	Sensor NTC-1k8 Thermokon			-50..150°C
146	0x92	Sensor NTC-5k Thermokon			-50..150°C
148	0x94	Sensor NTC-10k Thermokon			-50..150°C
150	0x96	Sensor NTC-20k Thermokon			-50..150°C
152	0x98	Sensor LM235			-40..120°C

Temperature measurement with data type signed int (register number is by 1 larger than above):

129	0x81	Sensor PT100	int16_t	0.1°C	-50..150°C
131	0x83	Sensor PT500			-50..150°C
...
153	0x99	Sensor LM235			-40..120°C
		Register value is 1 larger than above			

Measurement with interpolation chart:

Dec	Hex	Measuring range	Data type	Interpolation
240	0xF0	Voltage 0-10V	float	linear
241	0xF1		int16_t	linear
242	0xF2		float	exponential
243	0xF3		int16_t	exponential
244	0xF4	Voltage 0-10V Pullup 2kΩ at 5V	float	linear
245	0xF5		int16_t	linear
246	0xF6		float	exponential
247	0xF7		int16_t	exponential
248	0xF8	Resistance	float	linear
249	0xF9		int16_t	linear
250	0xFA		float	exponential
251	0xFB		int16_t	exponential

Interpolation chart

This chart can be used to convert and linearize values for sensors without a characteristic already defined in the device. The chart contains up to 10 nodes of the sensor characteristic to interpolate between.

Example: transformation from resistance to temperature for temperature sensors.

Register contents is stored in the EEPROM.

The description refers to temperature sensors. Other sensors than temperature sensors (e.g. humidity) are also possible and it is also possible to measure voltage instead of resistance.

These properties can be set in the configuration register:

Measuring range	voltage voltage, pullup 2k at 5 V (for ex. for LM235) resistance (normal case with temperature sensors)
Interpolation	sensor characteristic is nearly linear sensor characteristic is nearly exponential (for NTCs)
Data type of measuring range	float (unit 1 °C) signed int (unit 0.1 °C)

Node	Register-Address Temperature	Register-Address Resistance
1	24-25	26-27
2	28-29	30-31
...
10	60-61	62-63

The nodes are filled beginning at the top of the chart, with a maximum of 10, and end with temperature = resistance = 0, if there are less nodes. Temperature and resistance values have to be in ascending or descending order. So the combination 0,0 as a node is not allowed. Data type in the registers: float temperature, float resistance.

Function duty cycle

The duty cycle of the counter input S0+/S0- will be measured. Sample rate is 1 ms.

Modbus register

Discrete Inputs	
Addr.	Description
11	Value of counter input (switch connected to digital input S0) 0: inactive (switch open), 1: active (switch closed)

Input Registers / Holding Registers	
Addr.	Description
70	Value of digital inputs (read only) Same as Discrete Inputs 0-15
82 - 83	Active time of counter input May be written to initialize second count, simultaneously resets millisecond count Data type uint32, resolution 1 second Storage in EEPROM

Function pulse counter

The pulse counter records pulses of a energy meter with S0 interface, which is connected to the counter input S0+/S0-. There are also other applications possible.

Modbus register

Discrete Inputs		
Addr.	Name	Description
11	IN_C	Value of counter input (switch connected to digital input S0) 0: off (switch open), 1: on (switch closed)

Input Registers		
Addr.	Name	Description
70	INPUT	Value of digital inputs Same as Discrete Inputs 0-15
84 - 87	IZ	Pulse counter Data type uint64 (lower 48 bits are used, highest 16 bits are 0)
88 - 89	BZ	Calculated counter reading Data type uint32

Holding Registers		
Addr.	Name	Description
84 - 87	IT	Copy of pulse counter when key was pressed Value may be overwritten Data type uint64 (lower 48 bits are used, highest 16 bits are 0) Storage in EEPROM
88 - 89	AZ	Initial calculated counter reading Data type uint32 Factory default 0 Storage in EEPROM
90	IE	Pulses per unit Data type uint16 Factory default 1 Storage in EEPROM
91	WI	Ratio of current transformer Data type uint16 Factory default 1 Storage in EEPROM

Holding Registers		
Addr.	Name	Description
92	WU	Ratio of voltage transformer Data type uint16 Factory default 1 Storage in EEPROM
93	WP	Mode of calculation with current/voltage transformer Data type: flag in bit 0 Value 0...1, see below Factory default 0 Storage in EEPROM
94	ZS	Format of counter display Data type uint16 High byte contains total counter digits, range 0...9, factory default 7, higher values are limited to 9 Low byte contains fractional counter digits, range 0...3, factory default 1, higher values are limited to 3 Storage in EEPROM
95	TA	Flag for enabling the key Data type: flag in bit 0 Value 0: key is disabled, 1: key is enabled Factory default 1 Storage in EEPROM

Operating mode for calculation with transformation factor

In the WP register, there is a code 0...1 that determines, together with the transformation factors WI and WU, the way how they are included in calculation. WP, WI and WU depend on whether the transformers are switched by the counters, whether the counter indicates the consumption in a primary or secondary way and whether the emitted pulses correspond primarily or secondarily to the consumption.

A difference must be made between the following electricity meter types:

Type 1: Directly measuring counter, display: primary, pulse: primary

Note: Indicates the real consumption
 Species: DIN rail counter with mechanical drum-type counting mechanism, Ferraris counter
 Formula type: WP = 0
 Factors: WI = WU = 1

$$BZ = \left(\frac{IZ - IT}{IE} + AZ \right) \cdot WI \cdot WU, \quad BZ = \text{counter reading} = \text{consumption}$$

Type 2: Transformer counter, display: primary, pulse: secondary

Note: Indicates the real consumption
 Species: counter with LCD display
 Formula type: WP = 1
 Factors: WI and WU correspond to the transformers

$$BZ = \left(\frac{IZ - IT}{IE} \cdot WI \cdot WU \right) + AZ, \quad BZ = \text{counter reading} = \text{consumption}$$

Type 3: Transformer counter, display: primary, pulse: primary

Note: Indicates the real consumption
 Species: counter with LCD display, multi-function counters
 Formula type: WP = 0
 Factors: WI = WU = 1

$$BZ = \left(\frac{IZ - IT}{IE} + AZ \right) \cdot WI \cdot WU, \quad BZ = \text{counter reading} = \text{consumption}$$

Type 4: Transformer counter, display: secondary, pulse: secondary

Note: Indicates the consumption reduced by the transformation factors

Species: DIN rail counter with mechanical drum-type counting mechanism, Ferraris counter

Formula type: $WP = 0$

Consumption and display of the transformer counter are different. Both can be calculated using a different configuration (WI, WU).

Factors: $WI = WU = 1$:
The calculated counter reading corresponds to the display of the transformer counter.

Species: DIN rail counter with mechanical drum-type counting mechanism, Ferraris counter.

$$IZ - IT$$

$$BZ = \left(\frac{IZ - IT}{IE} + AZ \right) \cdot WI \cdot WU, \quad BZ = \text{counter reading or consumption}$$

Start of operation

The user reads on site the initial count from the electricity meter and presses the key on the MR-Multi I/O. After this key press, the pulse counter of register IZ is copied into register IT. Afterwards, the user configures the MR-Multi I/O via the Modbus using a service program.

The following must be entered:

- initial counter reading from the counter
- pulses per unit,
e.g. indication on the electricity meter 2000 pulses per kWh
- formula type for calculation with transformation factors
- factor for current transformation,
e.g. indication on the transformer 200/5A → factor = 40
- factor for voltage conversion,
e.g. indication on the transformer 20000/100V → factor = 200
- number of digits and places after the decimal point
- deactivate the key to protect the IT register

Details for calculation

The calculated counter reading should behave exactly as the electricity meter. This requires that there should be no overflows and rounding errors for the intermediate results. Therefore, particularly large data types are used for counting and calculation

Every 60 milliseconds, a pulse can be emitted by the electricity meter. This results in up to 1,440,000 pulses per day or about 526,000,000 pulses per year.

If the pulse counter was realized with 4 bytes, it could be count to 4,294,967,295. At highest pulse frequency, this would be enough for approx. 8.2 years.

Therefore it is provided with 6 bytes and cannot overflow.

The number of places after the decimal point is considered as an additional multiplier with a power of ten during the calculation. Furthermore, it determines the place of the decimal point in the display of BZ and AZ.

As for the electricity counter which only has a specified number of decimal places, the number of places is limited with the last step in the calculation. This is why the calculated counter reading of the MR-Multi I/O overflows to 0 as often as the counter reading of the electricity meter.

Calculated counter reading if WP = 0:

$$BZ = ((\text{uint96_t}) (IZ - IT) * WU * WI * \text{power of ten [places after decimal point]} / IE + (\text{uint96_t}) AZ * WU * WI) \% \text{ power of ten [counter digits]}$$

Calculated counter reading if WP = 1:

$$BZ = ((\text{uint96_t}) (IZ - IT) * WU * WI * \text{power of ten [places after decimal point]} / IE + (\text{uint96_t}) AZ) \% \text{ power of ten [counter digits]}$$

Note for other applications

For applications with a current meter it is required in order to maintain consistency of data that the pulse counter IZ cannot be deleted. However, it is possible to create a deletable counter with the calculated meter reading BZ by changing the values of IT and/or AZ via the bus.

A simple example without the different factors:

Configuration with: WP = 0, WU = WI = 1, IE = 1, places after decimal point = 0

Calculation: $BZ = IZ - IT + AZ$

When writing AZ = 0 and IT = IZ, the result is BZ = 0.

Modbus Function "43 /14 (0x2B / 0x0E) Read Device Identification"

Request

Read Device ID code:	0x01
Object ID	0x00

Response

Device ID code	0x01
Conformity level	0x01
More follows	0x00
Next object ID	0x00
Number of objects	0x03
Object ID	0x00
Object Length	0x11
Object Value	"METZ CONNECT GmbH"
Object ID	0x01
Object Length	0x0B
Object Value	"MR-Multi-IO"
Object ID	0x02
Object Length	0x04
Object Value	"V1.2"

MR-LD6

I/O commands

Modbus Function "01 (0x01) Read Coils"

Modbus Function "03 (0x03) Read Holding Registers" (R)

Modbus Function "04 (0x04) Read Input Registers" (R)

Modbus Function "06 (0x06) Write Single Register" (W)

Modbus Function "16 (0x10) Write Multiple Registers" (W)

Information

Read Discrete Inputs	(0 - 15)
Read Coils	(0 - 31)
Write Multiple Coils	(0 - 31)
Write Single Coil	(0 - 31)
Read Input Registers	(0 - 99)
Read Holding Registers	(0 - 99)
Write Multiple Registers	(0 - 99)
Write Single Register	(0 - 99)

Function block Bus-Watchdog

The Modbus communication can be monitored with a watchdog timer. The timer restarts with every valid message sent to the device. Only the device address is of importance, not the rest of the message content. If the master or the connection fails and the timer expires, the outputs are switched to their default setting (safe state) and the red LED lights up. With the time constant of 0 the watchdog timer is inactive. The monitoring is only valid when the relays are controlled via the Modbus.

Holding Registers		
Addr.	Description	
66	BusTimeout	<p>Time constant of communication monitoring</p> <p>The time applies only when the relays are controlled via Modbus. The relays switch into the inactive state when the timeout is reached. The time restarts with each valid message that is addressed to the device.</p> <p>Data type uint16, resolution 10 ms</p> <p>Maximum value = 65535 (= 655.35 seconds = 10.9 minutes)</p> <p>Factory default 0 (watchdog inactive)</p> <p>Storage in EEPROM</p>

When defining the time constant several items have to be considered that influence how often a specific slave will be addressed:

- Baud rate of the system
- Number of slaves
- Length of the messages of each slave
- Priorities while addressing the slaves
- Transmission errors cause timeouts and repetitions
- Capability and processor load of the master

Discrete Inputs (Read-Only)		
Addr.	Name	Description
0...5	LeakDetect_1 ... LeakDetect_6	Status bits for the identified leaks A bit is set when $SensorResist < SensorThresh$. The $SensorThresh$ hysteresis of $\pm 5\%$ applies for comparison.
16...21	CableBreak_1 ... CableBreak_6	Status bits for the identified cable breaks A bit is set when $ZenerVoltage > ZenerThresh$. The $ZenerThresh$ hysteresis of $\pm 2.5\%$ applies for comparison.

Input Registers (Read-Only)		
Addr.	Name	Description
0	LeakDetect	Status register for identified leaks in bit 0...5, the bits LeakDetect_1...6 are collected here
1	CableBreak	Status register for cable breaks in bit 0...5, the bits CableBreak_1...6 are collected here
2...7	SensorResist_1 ... SensorResist_6	Measured resistance values of the sensor, resolution, unit: 100 Ohm Maximum: 10000 (= 1 MOhm)
8...13	ZenerVoltage_1 ... ZenerVoltage_6	Voltages at the Z-diodes for wire break monitoring, resolution, unit: 100 mV

Coils		
Addr.	Name	Description
0...1	Relay_1 ... Relay_2	<p>Switching state of a relay (0 = ON, 1 = OFF) read-only for leakage identification or level monitoring, also writable when controlled via Modbus.</p> <p>The inactive states are defined in RelayPolarity, the active states are oppositely in each case.</p> <p>Leakage message: Active state if a leak is signaled.</p> <p>Level monitor: Active state if both electrodes are touched, inactive state if none of the electrodes is touched keep state if only one of the electrodes is touched.</p> <p>Control via Modbus: Basic setting is the inactive state.</p>

Holding Registers		
Addr.	Name	Description
0	Relay	Switching state of the relays in bit 0...1, the bits Relay_1...2 are combined here.
1	RelayPolarity	<p>The two relays have make contacts with switching state "OFF" or "ON". They are triggered with the states "inactive" or "active" by the leakage/level monitoring.</p> <p>The switching state can be inverted with this register. Bit 0...1 correspond to the inactive states of the two relays: 0: inactive = OFF, active = ON, 1: inactive = ON, active = OFF.</p> <p>Factory default 0b00, Storage in EEPROM</p>

Holding Registers		
Addr.	Name	Description
2...7	SensorThresh_1 ... SensorThresh_6	Switching thresholds for the sensor resistances Data type uint16, Resolution: 100 Ohm, Factory default 200 (= 20 kOhm), Storage in EEPROM
8...13	ZenerThresh_1 ... ZenerThresh_6	Switching thresholds for the Z-diodes for wire break monitoring Data type uint16, Resolution 100 mV, Factory default 110 (= 11 V), Storage in EEPROM
14 15	Mode_1 Mode_2	Operating mode for relay 1 and 2 0: Leakage message, 1: Level monitor (input 1 top, 2 bottom), 2: Level monitor (input 3 top, 4 bottom), 3: Level monitor (input 5 top, 6 bottom), 4: Combinatorial function for inputs, otherwise: control via Modbus. Factory default 0, Storage in EEPROM
16 17	LeakEnable_1 LeakEnable_2	Analog inputs for leakage message with relays 1 / 2. If bits 0...5 are set, the respective bits in LeakDetect in the operating mode leakage message make relays 1 or 2 switch into the active state. Factory default 0b000111 (LeakEnable_1), Factory default 0b111000 (LeakEnable_2), Storage in EEPROM
18	ZenerEnable	Inputs with installed cable monitoring. The respective bits in CableBreak are only set in case of a cable break if bits 0...5 are set. Factory default 0b111111, Storage in EEPROM

Holding Registers		
Addr.	Name	Description
19 20	BreakEnable_1 BreakEnable_2	<p>Inputs for the cable break message with relays 1 / 2.</p> <p>If bits 0...5 are set, the respective bits in CableBreak in the operating mode leakage message make relays 1 or 2 switch into the active state.</p> <p>Factory default 0b000000 (BreakEnable_1), Factory default 0b000000 (BreakEnable_2), Storage in EEPROM</p>
21...28 29...36	RelayMatrix_1 RelayMatrix_2	<p>Register for the combination of the inputs</p> <p>Bits 0...8 are used. The value in the registers corresponds to the switching state of the respective relay at all possible input combinations. The combinations are calculated as follows: Reg(X), Bit(Y) = desired relay state (1 / 0) where $X = (DI1 * 2^0 + DI2 * 2^1 + DI3 * 2^2 + DI4 * 2^3 + DI5 * 2^4 + DI6 * 2^5) // 8 + 21$ (bzw. 29) $Y = (DI1 * 2^0 + DI2 * 2^1 + DI3 * 2^2 + DI4 * 2^3 + DI5 * 2^4 + DI6 * 2^5) \% 8$ </p> <p>Factory setting 0, Storage in EEPROM</p>

Modbus Function "43 / 14 (0x2B / 0x0E) Read Device Identification"

Request

Read Device ID code: 0x01
Object ID 0x00

Response

Device ID code 0x01
Conformity level 0x01
More follows 0x00
Next object ID 0x00
Number of objects 0x03
Object ID 0x00
Object Length 0x11
Object Value "METZ CONNECT GmbH"
Object ID 0x01
Object Length 0x06
Object Value "MR-LD6"
Object ID 0x02
Object Length 0x04
Object Value V1.1"